

# 2ch Digital Air Micrometer

## DAG2200 Handling Instructions Manual



**SKS** CORPORATION

## ■ Request Prior to Utilization of Product

Please follow the following points in order to ensure the safe utilization of the product.

### [Dangers]

- ① The product has a few hundred volts of power inside.  
When installing, transferring, maintaining and inspecting the product and the connected devices/equipment, make sure to cut off all power sources and pull out the connection cables first before proceeding with the desired operation.
- ② The standard attached power cable is for 100V. Use the separately sold 250V power cable when the power supply exceeds 125V.
- ③ Do not step on or pull the power cable and the cables connecting equipment and machines. In addition, make sure to pull the power and connection cables at the plug to avoid damaging the cables. Never use damaged power and connection cables because doing so may cause electric shocks.
- ④ Make sure to set up the earth wire.  
The breakdown of the product or electric leaks from the product may cause electrocution.

### [Warning]

- ① This product is a precision device that performs measurements with the use of air. Please use clean air that is rid of dirt, water particles and oil.
- ② Do not insert any foreign materials (particularly materials that conduct electricity) into the product to avoid serious injuries brought about by electric shocks, fire and machine breakdown.

### [Caution when using the product overseas]

When bringing the product overseas, make sure to check the local laws and regulations in the country where the product will be utilized. Please note that we shall not be held liable for defects occurring on the product when it is used overseas.

### [About this Manual]

- ① This Manual was generated to ensure the safe use of the product. In the off-chance that there are doubts/problems on the product, oversights, and other matters that need to be clarified, please feel free to contact our sales department.
- ② Portions or the entire contents of this manual may not be used or reproduced without permission.
- ③ The specifications of the products, and the contents and external appearance of this manual may change without prior notice.

**[About this Warranty]**

This product is subject to warranty against defects in accordance with the following warranty-related regulations of our company:

- ① When the product has been broken or damaged due to the inappropriate handling of the customer, we reserve the right to demand payment needed in repairing the product even if the product is still within the warranty period.
- ② We reserve the right to decline the repair of products that have been remodeled or dismantled by the customer.
- ③ Products subject to repair are basically accepted at our service centers. In the event that our repairmen would need to travel to repair the product, we shall be charging the client with separate business travel expenses even if the product is still within the warranty period.

## Table of Contents

<b>Chapter 1</b>	<b>Introduction</b>	-----	<b>1</b>
1.1	Overview	-----	1
1.2	Special Features	-----	1
1.3	Block Diagram	-----	2
<b>Chapter 2</b>	<b>Names and Functions of Parts</b>	-----	<b>4</b>
<b>Chapter 3</b>	<b>Procedure Prior to Startup</b>	-----	<b>5</b>
3.1	Installation	-----	5
3.2	Preparations	-----	5
3.3	Startup	-----	6
<b>Chapter 4</b>	<b>Procedure Up to Measurement</b>	-----	<b>7</b>
4.1	Normal Condition	-----	7
4.2	Changing Workpiece Tolerance (Judgment Limits)	-----	8
4.3	When Connecting Measurement Devices for the First Time	-----	9
4.4	When Connecting Several Measurement Devices	-----	10
<b>Chapter 5</b>	<b>Master Setting Mode</b>	-----	<b>11</b>
5.1	Minimum Master Setting	-----	11
5.2	Maximum Master Setting	-----	13
5.3	Sensor Regulation	-----	15
5.4	Clearing of Master Setting Data	-----	19
5.5	Master Setting Procedure	-----	21
5.6	Master Setting Errors	-----	23
<b>Chapter 6</b>	<b>Measurement Mode</b>	-----	<b>24</b>
6.1	Requesting for Master Setting	-----	24
6.2	During Measurement (Upon Completion of Master Setting)	-----	25
6.3	When Putting Measurement Values on Hold	-----	28
<b>Chapter 7</b>	<b>Change Program Mode</b>	-----	<b>29</b>
<b>Chapter 8</b>	<b>Setting Mode</b>	-----	<b>30</b>
8.1	Explanation of Screen Display	-----	30
8.2	Structure of Setting Mode	-----	31
8.3	Setting Details	-----	31
<b>Chapter 9</b>	<b>External Input/Output Functions</b>	-----	<b>34</b>
9.1	Serial (RS232C) Communication Functions	-----	34
9.2	External Switch Input/Output	-----	35
<b>Chapter 10</b>	<b>Operation Flow</b>	-----	<b>36</b>
<b>Chapter 11</b>	<b>Measurement Sample</b>	-----	<b>47</b>
11.1	Taper Measurement	-----	47
11.2	2-Series Measurement of Inside Diameters	-----	49
<b>Chapter 12</b>	<b>Maintenance</b>	-----	<b>51</b>
<b>Chapter 13</b>	<b>Troubleshooting</b>	-----	<b>52</b>
<b>Chapter 14</b>	<b>Others</b>	-----	<b>53</b>
14.1	Model	-----	53
14.2	Options	-----	54
14.3	Specifications	-----	55
<b>Chapter 15</b>	<b>Worksheet</b>	-----	<b>57</b>

# Chapter 1 Introduction

Thank you for purchasing this 2-channel digital air micrometer (DAG2200).

This manual was designed for all types of people. Even people who will be using an air micrometer for the first time will find this manual extremely helpful when it comes to the utilization of the rich lineup of functions possessed by this product.

Please carefully read this manual before using the product.

## 1.1 Overview

- This product detects the fluctuations in the air pressure from the dimensions of the subject with the help of the pressure sensor, and then displays a digital evaluation of such via the dimension display, lamps and bar display.
- This product is a precision comparator (gauge).  
This measures objects with the measured master as the standard. Now further precision can be achieved through the periodic setting or coordination of the master.
- This product can judge if the measured value is OK or NG (no good).  
The judgment of the measured values can be quickly identified through the various colors in the main display and the judgment LED. In addition, the periodic master setting can be done through the panel keys.

## 1.2 Special Features

- ① The judgment results (OK or NG) of the measurement/calculation can be easily identified through the numbers, lamp color and bar display
- ② The measurement and calculation results can be switched with one push of a button
- ③ Master setting is easy
- ④ Peak measurement [Option]
  - +PEAK, -PEAK, TIR (=+PEAK-(-PEAK)), TIR/2 (=+PEAK-(-PEAK))/2)
  - Auto-measure start/stop function
- ⑤ A maximum of 99 ranks (OK range) can be judged [Option]
- ⑥ A rich lineup of external input/output functions
  - Serial communication function  
RS232C enables data output of measurement and judgment results to a personal computer or printer [Standard]
  - External switch input function  
Measurement and master setting commands can be relayed through a foot switch or a push-button switch [Standard]
  - Digimatic output function  
Measured values can be printed out to a digimatic printer [Option]
  - DC input/output function  
Judgment results can be relayed to the lamp, sequencer and so on, and the BCD output of measured values can also be done. [Option]


In addition, the measurement and master setting commands can be inputted from outside the unit.

- ⑦ Compact  
150 (width) x 180 (thickness) x 194 (height)  
With regulator (optional) = 275 (thickness) mm (excluding the protruding parts)

### 1.3 Block Diagram


- ① Structural Drawing

The arrows illustrate the direction of the air and the electric signals  
Those inside the [ ] are options.





## ② Operation Flow

The following flowchart shows the process from the turning on of the power supply to the loading/running of the software.



## Chapter 2 Names and Functions of Parts



## Chapter 3 Procedure Prior to Startup

### 3.1 Installation

Place the unit and the measurement devices in a stable place that can sufficiently hold heavy articles

### 3.2 Preparations

#### (1) Air Piping


Install the piping for the air that will be used in measurement.

Make sure to supply the unit with clean air that is rid of dirt, water and oil particles.


Please have high-performance filters ready in case the air environment requires them.

**Caution** When connecting the hose in the coupler, make sure that there are no air leaks.


Connection of the Filter (Optional)



#### (2) Connection of Power Supply Cable



#### (3) Connection of Measurement Devices



### 3.3 Startup



- ① Turn OFF the power supply switch (press -).
- ② The LCD Display will show the software version, optional information, etc.
- ③ The unit will read the last used setting values..
- ④ Check the light of the screen (visually).
- ⑤ Start the measurement mode (master request screen).

■ POINT


- Immediately after turning on the unit, it will start with the Measurement mode (master request screen).

## Chapter 4 Procedure Up to Measurement

This chapter contains the procedures up to measurement in each condition.


### 4.1 Normal Condition

The following is the procedure up to measurement under normal conditions (Piping/wiring to the unit, connection of measurement devices, inputting of the master values, judgment limits and other setting values, and sensor regulation have been completed).



#### 4.2 Changing Workpiece Tolerance (Judgment Limits)


The following illustrates the procedure up to measurement when the tolerance of the workpiece has changed.



### 4.3 When Connecting Measurement Devices for the First Time

The following illustrates the procedure up to measurement when a measurement device will be connected to the unit for the first time.


**Caution:** Regulating the sensors/detectors may not be necessary in some measurement devices.



#### 4.4 When Connecting Several Measurement Devices

The following illustrates the procedure up to measurement when several measurement devices will be connected to a single unit.

In case the inputting of the settings needed by the measurement devices has not been completed, please refer to “Chapter 3-3.3 When Connecting Measurement Devices for the First Time.”



## Chapter 5 Master Setting Mode

This product is a comparator, so master setting (correction of the measurement values) through the master is required.


In addition, the measurement functions of the device can be made more precise by performing regular master settings.

There are 2 master (Minimum and Maximum Master) setting methods (Zero and Magnification/Sensitivity Correction) in this product.

### Caution

- After performing master setting, if the zero/magnification knob was moved or operated, make sure to redo master setting.
- In case the master setting lamp is red and blinking and the LCD display shows “Master Request”, then there is an error in the master setting. Conduct master setting again.
- Check if there are foreign materials in the master and the measurement devices. Foreign materials could have bad effects in the correction process and could cause incorrect measurements.

### 5.1 Minimum Master Setting




- Displays the Minimum Master Setting screen
- Shows the measurement values of the master setting without corrections

- The red and orange lights will blink repeatedly when there is Master Setting NG
- The green and orange lights will blink repeatedly when master setting is OK

- Green light will be displayed when the measurement values [ $\mu\text{m}$ ] (Channel A values at the top and Channel B values at the bottom) of the master setting without corrections is within the minimum master setting range (measurement range  $\pm 50\%$ ), while it will display red when the values are outside the range.
- If the display range of the bar has been exceeded, the right end of the bar will blink.
- If any of the channels is [NO USE], then the channel that will not perform master setting will be turned off.

Master Setting Mode (Minimum (Range) Master Setting Screen)

□ In case the [Master Set Way] has been set to [ALL]



Master Setting Mode (Minimum Master Setting Screen)


□ In case the [Master Set Way] has been set to [EACH]

**[Explanations]**

- This is the minimum master setting screen. Please set the minimum (range) master.
- The measurement values shown in the main display and in the LCD display are values that have not been corrected.
- The dark orange light at the left side of the bar shows the minimum master values, while the dark orange light on the right shows the maximum master values.
- The minimum (range) master setting can be performed when the main display has turned green.
- Minimum (range) master setting may not be performed when the main display is red. When master setting will still be done, make sure to regulate the sensor (please refer to 5.3 Sensor Regulation).
- Pressing would move the unit to the Measurement Mode.
- Every push of the button will switch the bar display range in three steps.
- When the [Master set way] is set to [Each], pressing the button will switch operation to the channel that will perform master setting.
- Pressing would transfer the screen to the Sensor Regulation screen.
- Pressing would proceed to the Minimum (Range) Master Setting.

- When the Minimum (Range) Master Setting is OK, then the unit will proceed to the Maximum (Range) Master Setting. When the Minimum Master Setting is NG, the screen will display ERROR. The ERROR display can be erased by pressing **ENT** or the **RST** button once. Now after performing sensor regulation (please refer to 5.3 Sensor Regulation), perform master setting again.

## 5.2 Maximum Master Setting




- Displays the Maximum Master Setting screen
- Shows the measurement values of the master setting without corrections

- The red and orange lights will blink repeatedly when there is Master Setting NG
- The green and orange lights will blink repeatedly when master setting is OK

Master Setting Mode (Maximum (Range) Master Setting Screen)  
 In case the [Master Set Way] has been set to [ALL]

- Green light will be displayed when the measurement values [ $\mu\text{m}$ ] (Channel A values at the top and channel B values at the bottom) of the master setting without corrections is within the maximum master setting range (measurement range  $\pm 20\%$ , or within 0.5~2.0 times), while it will display red when the values are outside the range.
- If the display range of the bar has been exceeded, the right end of the bar will blink.
- If any of the channels is [NO USE], then the channel that will not perform master setting will be turned off.



Master Setting Mode (Maximum (Range) Master Setting Screen)  
 In case the [Master Set Way] has been set to [EACH]

### [Explanations]


- This is the maximum (range) master setting screen. Please set the maximum (range) master.
- The measurement values shown in the main display and in the LCD display are values that have not been corrected.
- The dark orange light at the left side of the bar shows the minimum master values, while the dark orange light on the right shows the maximum master values.
- The maximum (range) master setting can be performed when the main display has turned green.
- Maximum (range) master setting may not be performed when the main display is red. When master setting will still be done, make sure to regulate the sensor (please refer to 5.3 Sensor Regulation).

- Every push of the  button will switch the bar display range in three steps.
- Pressing  would move the screen to the Sensor Regulation screen.
- Pressing  would move the unit to the Minimum (Range) Master Mode.
- Pressing  would proceed to the Maximum (Range) Master Setting.

When the Maximum (Range) Master Setting is OK, then the unit will display that the master set is OK and then proceed to the Measurement Mode. When the Maximum (Range) Master Setting is NG, the screen will display ERROR.

The ERROR display can be erased by pressing  or  button once. Now after performing sensor regulation (please refer to 5.3 Sensor Regulation), perform master setting again.

### 5.3 Sensor Regulation



#### [Explanations]

- This is the Sensor Regulation screen. Please adjust the sensor. (Refer to [Regulation Procedure])
- The measurement values shown in the main display and in the LCD display are values that have not been corrected.
- The dark orange light at the left side of the bar shows the minimum master values, while the dark orange light on the right shows the maximum master values.
- Every push of the  button will switch the unit in this manner: <<Channel A & Channel B>>  <<Calculated Values of Channel A & Channel B>>. (When the [CALC Function] is in position other than in NO USE, or when the master values of Channels A & B are similar)
- Every push of the  button will switch the bar display range in three steps.
- Pressing   would move the unit to the Minimum (Range) Master Mode.
- Pressing the  would move the operation to the screen for clearing the Master Setting data.

[Regulation Procedure]

The regulation procedure for the inside and outside diameters differ.

When regulating the sensor of Channel A

1) Inside Diameter

Master

Minimum Range



Master (Left)

Maximum Range

Master (Right)



Measurement Device



- ① Set the Minimum (Range) Master into the measurement device
- ② Turn the ZERO Regulation knob, and then match the Channel A display close to the value of the Minimum (Range) Master.

Master

Minimum Range



Master (Left)

Maximum Range


Master (Right)



Measurement Device




- ③ Set the Maximum (Range) Master into the measurement device
- ④ If the Channel A display:
  - Is close to the value of the Maximum (Range) Master, then the regulation is completed. Proceed to ⑦.
  - Did not reach the maximum master value, then there is insufficient sensitivity/magnification. Proceed to ⑤.
  - Exceeded the max. master value, then there is excessive sensitivity or magnification. Proceed to ⑥.



⑤ When there is insufficient magnification/sensitivity in the sensor:

- While the Maximum (Range) Master is set in the measurement device, turn the sensitivity regulation knob clockwise, then adjust the  $-5\times$  of the maximum master values to the positive (+) side.
- Turn the Zero regulator knob clockwise and then match the values to the maximum master values.
- Repeat from ①.



⑥ When there is insufficient magnification/sensitivity in the sensor:

- While the Maximum (Range) Master is set in the measurement device, turn the sensitivity regulation knob counterclockwise, then adjust the  $+5\times$  of the maximum master values to the negative (-) side.
- Turn the Zero regulator knob counterclockwise and then match the values to the maximum master values.
- Repeat from ①.

⑧ The regulation/adjustment of the sensor of Channel A is complete.


Adjust the sensor of Channel B in the same manner.

Except in special cases, future regulations/adjustments of the sensor would not be necessary.

When regulating the sensor of Channel A

## 2) Outside Diameter


Master  
Minimum Range  
Master (Left)      Measurement Device  
Maximum Range  
Master (Right)



- Set the Maximum (Range) Master into the measurement device
- Turn the ZERO Regulation knob, and then match the Channel A display close to the value of the Maximum (Range) Master.

Master  
Minimum Range  
Master (Left)  
Maximum Range  
Master (Right)

Measurement Device



③ Set the Minimum (Range) Master into the measurement device

④ If the Channel A display:

- Is close to the value of the Minimum (Range) Master, then the regulation is completed. Proceed to ⑦.
- Did not reach the minimum master value, then there is insufficient sensitivity/magnification. Proceed to ⑤.
- Exceeded the min. master value, then there is excessive sensitivity or magnification. Proceed to ⑥.

⑤ When there is insufficient magnification/sensitivity in the sensor:

- While the Minimum (Range) Master is set in the measurement device, turn the sensitivity regulation knob clockwise, then adjust the +5x of the minimum master values to the negative (-) side.
- Turn the Zero regulator knob clockwise and then match the values to the minimum master values.
- Repeat from ①.

⑥ When there is insufficient magnification/sensitivity in the sensor:

- While the Minimum (Range) Master is set in the measurement device, turn the sensitivity regulation knob counterclockwise, then adjust the -5x of the minimum master values to the positive (+) side.
- Turn the Zero regulator knob counterclockwise and then match the values to the minimum master values.
- Repeat from ①.

⑦ Perform steps ①~⑥ for both Channels A and B.

⑧ The regulation/adjustment of the sensor of Channel A is complete.


Adjust the sensor of Channel B in the same manner.

Except in special cases, future regulations/adjustments of the sensor would not be necessary.

## 5.4 Clearing the Master Setting Data

This section discusses the method for clearing the zero correction and sensitivity correction data.

This is not normally used. Use this when checking for abrasions/wear and tear on the measurement device.




Master Setting Mode (Clearing the Master Setting Data)


### [Explanations]

- This is the screen for clearing the Master Setting Data.
- Pressing would move the unit to the Minimum (Range) Master screen.

If the button is pressed, then after clearing the master setting data, “Master clear OK!” and “Set the master” will be shown in the LCD display, and the screen will move to the Minimum (Range) Master Setting screen.


### [Procedure]







## 5.5 Master Setting Procedure

This section discusses the procedure for correcting the zero setting through the minimum range master, and the sensitivity (magnification) through the maximum range master.







## 5.6 Master Setting Errors

When there are master setting errors, the following error details will be displayed on the alphanumeric display.


Master set way	Outside the Zero Correction Range	Outside the Sensitivity Correction Range
ALL	ZERO ERR	GAIN ERR
EACH	ZERO Set error	Zero Set Error

In case the abovementioned errors are displayed, check the master that was used. If there are no problems with the master, then adjustments via the zero/sensitivity regulator knob would be necessary. (Refer to 5.3 Sensor Regulation)

Pressing the **ENT** or **RST** button will erase the error message.

## Chapter 6 Measurement Mode

### 6.1 Requesting for Master Setting




When Requesting for Master Setting  
(Main Measurement Screen)

- Displays the master setting request message and the present program number.

- The red light will blink when there is Master Setting NG, while the green light will light up when it is OK.

- The measurement values [ $\mu\text{m}$ ] (Channel A values at the top and channel B values at the bottom) that require master setting will be shown in orange.
- If the display range of the bar has been exceeded, the right end of the bar will blink.



Master Setting Request Screen  
(Main Calculation Screen)

- The raw calculation data [ $\mu\text{m}$ ] (the calculation method can be changed in the settings) that require master setting will be shown in orange.
- If the display range of the bar has been exceeded, the right end of the bar will blink.


#### [Explanations]

- In this condition or stage, the measurement values cannot be put on hold.
- The dark orange light at the right side of the bar shows the maximum judgment values, while that on the left shows the minimum judgment values.

- The screen shown above is the usual display when the unit is turned on. When the master setting is OK, then any button pressed will erase the message and measurement can be performed.
- Every push of the  button will switch the main measurement and main calculation screens. (When ‘NO USE’ is selected in the ‘CALC Function,’ then it will only be the main measurement screen.)
- Pressing the  button for 3 seconds will switch the screen to the Setting Mode.
- Pressing the  button for 3 seconds will switch the screen to the Master Setting Mode.
- Pressing the  button for 3 seconds will switch the screen to the Program Switch Mode


## 6.2 During Measurement

- When NO USE is chosen with regard to the CALC Function:
  - The top is the display for Channel A (in mm). (The display resolution can be changed.)
  - The bottom is the display for Channel B (in mm). (The display resolution can be changed.)
  - \*In the above cases, the displayed values are raw and have not been corrected.
- For the other cases:
  - The top is the display for the calculation values (in mm). (The display resolution and the calculation method can be changed.)
  - The bottom is the bar graph of the calculation values.




During Measurement  
(Main Measurement Screen)

- The general judgment lamp will light up (the OK light will be on when the measurement and calculation values are OK, and the NG light will be on when there are errors).
- The red light will switch on.
- This will be green when the measurement values [ $\mu\text{m}$ ] that have been corrected through master setting (Channel A values at the top and channel B values at the bottom) are OK, and red if NG.
- If the display range of the bar has been exceeded, the right end of the bar will blink.



During Measurement  
(Main Calculation Screen)

- When NO USE is chosen with regard to the CALC Function:
  - The top is the display for Channel A (in mm). (The display resolution can be changed.)
  - The bottom is the display for Channel B (in mm). (The display resolution can be changed.)
- For the other cases:
  - The top is the display for the calculation values (in mm). (The display resolution and the calculation method can be changed.)
  - The bottom is the bar graph of the calculation values.




During Measurement  
(Main General Judgment Screen)

## [Explanations]

- This shows that the unit is in the Measurement Mode.
- The displayed values have been corrected through: ①the display resolution, ②master setting, and ③display value shift.
- The dark orange light at the left side of the bar shows the –NG/OK limits, while that on the right shows the OK/+NG limits.
- When “NO USE” is selected for “CALC Function,” then the general judgment lamp will perform overall judgment in Channel A and Channel B. If any of these channels chose “NO USE,” then the judgment will be made on the channel that can be used. In case options other than “NO USE” is chosen in the “CALC Function,” then general judgment can be made on Channel A, Channel B and the calculation values.
- Every push of the  button will switch the main measurement and master setting screens, and the main screen for the general judgment. (When “NO USE” is selected in the “CALC Function, then the main calculation screen will not be an option.)
- Pressing the  button for 3 seconds will switch the screen to the Setting Mode.
- Pressing the  button for 3 seconds will switch the screen to the Master Setting Mode.
- Pressing the  button for 3 seconds will switch the screen to the Program Switch Mode
- Pressing the  button will put the measurement values on hold. (Refer to “6.3 Holding the Measurement Values) When the external I/F is being used, then together with the measurement values being frozen (or on hold), the measurement values, judgment results and other elements will be generated as output. (When the “External switch” is in “Not hold,” the values cannot be put on hold.)


### 6.3 When Putting Measurement Values on Hold



Freezing Measurement Values  
(Main Measurement Screen)

- The green light will switch on.


- The values during measurement will be put on hold (or frozen).
- The display color will turn from light → dark.



Freezing Measurement Values  
(Main Calculation Screen)

- The display color will turn from light → dark.
- The “CALC” and “Hold” messages will be repeated alternately.

- The values during measurement will be put on hold (or frozen).
- The display color will turn from light → dark.



Freezing Measurement Values  
(Main General Judgment Screen)


- The values during measurement will be put on hold (or frozen).

- The display color will turn from light → dark.

#### [Explanations]

- When erasing the frozen measurement values and returning to the measurement process, press **RST** or input the RESET signals.
- The measurement values cannot be frozen when the master setting was NG.

## Chapter 7 Change Program Mode




Change Program Mode

### [Explanations]

- Pressing the  button for 3 seconds will switch the screen to the Change Program mode.
- “Change PROG mode” will be displayed at the top of the LCD screen, while the number of the program that is being currently used will be shown at the bottom.
- Choose the number (1~10) of the program that you want to use by pressing   or  .
- When the  button is pressed, the program will be loaded, and the unit will switch from the Change Program mode to the Measurement mode.
- When the  button is pressed, the program will stay as is (unchanged), and the unit will switch from the Change Program mode to the Measurement mode.
- When the device is turned on, it will start with the program number that was last selected and used.

## Chapter 8 Setting Mode

### 8.1 Explanation of the Screen




- The setting item will be shown at the top, while the setting values and the selected numbers will be displayed at the bottom.

#### [Explanations]

- Pressing the  button for 3 seconds will switch the screen to the Measurement mode.
- When inputting the setting values, the inputted values will change by pressing  .  
(The numbers are lined up in a loop, so that when the DOWN key is pressed when it is at 1, it will get to 9, while when the UP key is pressed when it is at 9, it will go to 1.)
- When inputting the setting values, the digit of the inputted values will change by pressing  .  
(The cursors form a loop in such a way that when the cursor is at the rightmost digit and the RIGHT key is pressed, the cursor will move to the leftmost digit, and the other way around when the left key is pressed when the cursor is at the leftmost digit.)
- When choosing the item, the items will change by pressing  . (Refer to "Chapter 10 Operation Flow")

## 8.2 Structure of the Setting Mode



## 8.3 Setting Details

This section discusses the setting item names and setting details in the Setting Mode.

Roughly classified, the Setting mode can be divided into the following 3:

- Normal     …     The master values, judgment limits and other factors can be set
- Detail     …     The measuring range, display resolution, polarity, calculation method, master setting method and so on can be changed
- System     …     The external switch input, average shift frequency and so on can be changed

- ① Setting Item Names and Setting Details in NORMAL
- Settings Related to the Master Data
  - 「MIN M. of A(B)」 …     Input the minimum master setting range for each channel
  - 「MAX M. of A(B)」 …     Input the maximum master setting range for each channel

- Settings Related to the Judgment Limits
  - 「-NG/OK of A(B)」 … Input the –NG and OK judgment limits for each channel
  - 「OK /+NG of A(B)」 … Input the OK and +NG judgment limits for each channel
  - 「-NG/OK of CALC」 … Input the –NG and OK judgment limits of the calculation results
  - 「OK /+NG of CALC」 … Input the OK and +NG judgment limits of the calculation results
- Settings Related to the Master
  - 「CORRECT of A(B)」 … The corrected instrumental errors of each channel can be set  
The above setting data will be added onto the corrected master data, and then displayed.  
The setting can be within +0.9999~ -0.9999[mm].

② Setting Item Names and Setting Details in DETAILED

- 「Measuring range」 … The measurement range can be selected.
- 「Resolution」 … The display resolution can be selected.  
The display resolution that can be chosen vary depending on the measurement range.

- Settings Related to the Polarity
  - 「POLARITY of A(B)」 … The polarity of each channel can be selected.  
Choose + when the inside diameter will be measured, and – for the outside diameter.  
When only one channel will be used, make sure to select “NO USE” with regard to the polarity of the sensor of the channel that will not be used.  
In this case, the “CALC Function” will automatically choose “NO USE,” the “Master set way” will be set to “ALL,” and the inputting of the setting values will be skipped in the channel that will not be used.
- Settings Related to the Calculation Method
  - 「CALC Function」 … The calculation method can be selected in case the measurement values of Channels A and B will be calculated. If this is switched to “NO USE,” then the inputting of the judgment limits of the calculation results will be skipped.
- Settings Related to Master Setting
  - 「Master set way」 … The master setting method can be selected.

## ③ Setting Item Names and Setting Details in SYSTEM

- 「External switch」 … The input type of the external switch can be selected.
- 「Smooth time」 … The average shift frequency can be selected.
- 「Shift of A(B) (CALC)」… The nominal dimensions of Channels A&B and the calculation results can be set. The measurement values displayed in the Measurement mode are the figures that have already deducted the values inputted in this step.

Resolution [μm]	Shift of A(B) (CALC)						
0.02, 0.05	1	2	3	.	4	5	6
0.1, 0.2, 0.5	1	2	3	.	4	5	6
1, 2, 5	1	2	3	.	4	5	6

※Depending on the resolution, there are digits in which the settings may become void the

## Chapter 9 External Input/Output Functions

### 9.1 Serial (RS232C) Communication Function

#### (1) Overview

This product utilizes serial communication and can send the output containing the measurement/judgment values to the printer or computer (hereunder referred to as PC).


#### (2) Preparations

The “RS232C” at the back of this product is the connection to the printer or PC.

Connect these machines to the main body of the product with the use of the communication cable D-sub9P (male) that comes as an option.

#### (3) RS232C Connector

**Caution** Make sure that the cable is less than 15 meters long.



Pin No.	Signal
1	
2	RxD
3	TxD
4	
5	GND
6	
7	RTS
8	CTS

#### (4) Serial Port Settings

Settings	Setting Details
Baud Rate	9600
Bit/Characters	8
Stop Bit	1
Start Bit	1
Parity Bit	None

#### (5) Generation of the Measurement Results

The measurement data and the judgment results can be generated.

##### ① Simple Commands (Commands from the PC for the required data)

1. Send the “D” <44H> command. The data on ② below will be returned.  
(The commands are case sensitive, so make sure to use the capital “D”)
2. Send the “E” <45H> command. The measurement values will be frozen.  
(The commands are case sensitive, so make sure to use the capital “E”)
3. Send the “R” <52H> command, and the frozen measurement values will be erased.  
(The commands are case sensitive, so make sure to use the capital “R”)

② Simple Output Data

The following data will be returned.

String	I	T	E	M	1					-	2	5	.	0		-	N	G		
	I	T	E	M	2						1	2	.	5			O	K		
ASCII Code	I	T	E	M	3					N	O		U	S	E		N	J	G	CR
	49	54	45	4D	31	20	20	20	20	2D	32	35	2E	30	20	2D	4E	47	20	
	49	54	45	4D	32	20	20	20	20	20	31	32	2E	35	20	2O	4F	4G	20	
	49	54	45	4D	33	20	20	20	20	4E	4F	20	55	53	45	20	4E	4A	47	0D

(6) Data Transmission from the Main Device

In the Measurement mode, press **ENT** or the measurement switch (refer to “9.2 External Switch Input”).

The data will be transmitted in the “5 ②Simple Output Data” form.

**Caution** Data cannot be transferred when the master setting is NG.

## 9.2 External Switch Input

(1) Overview

External switch, foot switch and other devices that have no voltage at the contact point can be connected to the “SW. ETC” at the back of this product, and measurement and RESET can be done with the use of these devices.

(2) Preparations

The “SW. ETC” at the back of this product is the connection point for the external switches.

The D-sub9P (male) cable can be connected.

(3) Input Switch Connector

External switches, foot switches and other non-voltage connectors can be connected to this product.


Inputting will be effective or valid by shorting the GND pin (6).

Please use the D-sub15P (male).

**Caution**

- Make sure that the cable is less than 2 meters long.
- This product cannot be used in switches other than push-button and foot switches.
- When connecting the product to a sequencer and relay device, make sure to use the DC input/output board (option).
- Do not connect anything in the pin numbers that have no signals labeled on them. Doing so may cause breakdown in the product.

1



9 Maximum Master Setting  
10 Minimum Master Setting

GND 6  
Measurement 7  
RESET 8

15

(4) Operation Via the External Switches

a. Measurement Switch (Measurement)

① Press the “Measurement Switch” when in the Measurement mode.  
The measurement values will be sent to the external devices/machines.

**Caution** The values will not be sent if the master setting is NG.

② When in the “External swtch” item in the Settings:  
If “Hold” is selected, then the measurement data will be saved (or frozen) and the data will be generated.  
If “Not Hold” is chosen, then only the data outputting will be done.

b. RESET Switch

① This erases the “hold” (frozen) status of the measurement values.

c. Minimum Master Setting

① When in the Measurement mode, set the minimum (range)/zero master in the measurement device.  
② When the measurement value has stabilized, press the “Minimum Master Setting switch.”  
With this, the minimum (range) master setting will take place, and the unit will return to the Measurement mode.

d. Maximum Master Setting


① When in the Measurement mode, set the maximum (range)/zero master in the measurement device.  
② When the measurement value has stabilized, press the “Maximum Master Setting switch.”  
With this, the maximum (range) master setting will take place, and the unit will return to the Measurement mode.

**Caution**


- Perform the master setting in the following order: Minimum Master Setting → Maximum Master Setting
- The master setting will be done for Channels A&B together

## Chapter 10 Operation Flow

### [Activities In Between Modes], [Change Program Mode]




## [Master Setting Mode]





[Master set way]			
	[ALL]	[EACH]	
※1	MAX M.A: 123.4567 MAX M.B: 123.4567	Push [SET] B ← A MIN M.A: 123.4567	Perform maximum (range) master setting of Channel A
※2	MAX M.A: 123.0000 MAX M.A: 123.0000	Set MAX M. of A 123.0000	Perform minimum (range) master setting of Channel A
※3	Master set OK To measure mode		Master setting complete. Proceed to Measurement mode
※4	ADJ-A: 123.4567 ADJ-B: 123.4567		Regulate or adjust the sensor
※5	Master Clear? If OK, push ENT.		Clears the corrected data of the previous master setting

## [Setting Mode]



## [Setting Mode (Normal Setting)]





※1	MIN. M. of A	Input the minimum (range) master value of Channel A
※2	MAX. M of A	Input the maximum (range) master value of Channel A
※3	-NG/OK of A	Input the -NG/OK judgment limits of Channel A
※4	OK/+NG of A	Input the OK/+NG judgment limits of Channel A
※5	Correct of A	Input the corrected instrumental error of Channel A
※6	MIN. M. of B	Input the minimum (range) master value of Channel B
※7	MAX. M of B	Input the maximum (range) master value of Channel B
※8	-NG/OK of B	Input the -NG/OK judgment limits of Channel B
※9	OK/+NG of B	Input the OK/+NG judgment limits of Channel B
※10	Correct of B	Input the corrected instrumental error of Channel B
※11	-NG/OK of CALC	Input the -NG/OK limits of the calculation results
※12	OK/+NG of CALC	Input the OK/+NG limits of the calculation results

**[Setting Mode (Detail Setting)]**

**Detail**

**RST**

**ENT**

**Measuring range**

- 200 $\mu\text{m}$
- 100 $\mu\text{m}$
- 50 $\mu\text{m}$
- 20 $\mu\text{m}$
- 10 $\mu\text{m}$

**SET** **PROG** **DISP** **MAS**

**RST**

**ENT**

**Resolution**

- 5 $\mu\text{m}$
- 2 $\mu\text{m}$
- 1 $\mu\text{m}$
- 0.5 $\mu\text{m}$
- 0.2 $\mu\text{m}$
- 0.1 $\mu\text{m}$

**SET** **PROG** **DISP** **MAS**

**RST**

**ENT**

**Polarity of A**

**+** **-** **NO USE**

**SET** **PROG** **DISP** **MAS**

Select the input digit with the use of

**SET** **MAS**

and change the input values by pressing

**PROG** **DISP**

**\*1**

**\*2**

**\*3**

**\*5**


**CALC Function**

- NO USE
- A-B
- A+B
- (A+B)/2
- B-A
- (A-B)/2
- (B-A)/2

**SET** **PROG** **DISP** **MAS**


**RST**


**ENT**



※ In Normal setting, the 100μm and 50μm can be selected.

※1	Measuring range	Select the measurement range
※2	Resolution	Select the resolution
※3	Polarity of A	Select the polarity of the Channel A sensor
※4	Polarity of B	Select the polarity of the Channel B sensor
※5	CALC Function	Select the calculation method
※6	Master set way	Select the master setting method

**[Setting Mode (System Setting)]**




×1	External switch	Select the external switch operation
×2	Smooth times	Select average shift frequency
×3	Shift of A	Input the nominal dimensions of Channel A
×4	Shift of B	Input the nominal dimensions of Channel B
×5	Shift of CALC	Input the nominal dimensions of the calculation results

## Chapter 11 Measurement Sample

### 11.1 Taper Measurement

When measuring the taper of a cylinder as shown in the right diagram:

	ØD1	ØD2
Max. Range	12.0500	14.0500
Min. Range	11.9500	13.9500
Work Tolerance		
	+0.0450	
Channel A 12	-0.0450	
Channel B 14		+0.0450
		-0.0450
Taper Degree (B-A) 2		+0.0300
		-0.0300



- (1) Set the Program No. to 1.
- (2) Set the [Measuring range] to 100 $\mu$ m.
- (3) Channel A will be for the measurement of the outside diameter, so choose – for Polarity A.
- (4) Channel B will be for the measurement of the outside diameter, so choose – for Polarity B.
- (5) In order to see the taper degree (B-A), select B-A in the [CALC Function].
- (6) Choose ALL in the [Master set way].
- (7) Input the minimum (range) master value (11.9500) of Channel A.
- (8) Input the maximum (range) master value (12.0500) of Channel A.
- (9) Input the –NG/OK limits (11.9550 (=12-0.0450)) of Channel A.
- (10) Input the OK/+NG limits (12.0450 (=12+0.0450)) of Channel A.
- (11) Input the corrected instrumental error (+0.0000) of Channel A.
- (12) Input the minimum (range) master value (13.9500) of Channel B.
- (13) Input the maximum (range) master value (14.0500) of Channel B.
- (14) Input the –NG/OK limits (13.9550 (=14-0.0450)) of Channel B.
- (15) Input the OK/+NG limits (14.045 (=14+0.0450)) of Channel B.
- (16) Input the corrected instrumental error (+0.0000) of Channel B.
- (17) Input the –NG/OK limits (1.9700 (=2-0.030)) of the taper degree (B-A).
- (18) Input the OK/+NG limits (2.0300 (=2+0.030)) of the taper degree (B-A).
- (19) Select [WRITE] in the [Store set value].
- (20) Setting complete. Commence with the measurement after performing master setting


Setting Mode	Setting Item		Model	DAG2200	
			Prog. No.	[1]	
Detail	Measuring Range		Measuring Range		
	Resolution		Resolution		
	Channel A	Polarity	Polarity of A	+ <input type="checkbox"/> - <input checked="" type="checkbox"/>	
			Polarity of B	+ <input type="checkbox"/> - <input checked="" type="checkbox"/>	
	Calculation Method		CALC Function (Input calculation method)		
	Master Setting Method		Master set way	ALL <input checked="" type="checkbox"/> EACH <input type="checkbox"/>	
Normal	Channel A	Min. Master	MIN. M. of A (Input actual dimensions)		
		Max. Master	MAX M. of A ( " )		
		Judgment Limits	-NG/OK of A ( " )		
			OK/+NG of A ( " )		
		Corrected Instrumental Error	Correct of A (-0.9999~+0.9999)		
	Channel B	Min. Master	MIN. M. of B (Input actual dimensions)		
		Max. Master	MAX M. of B ( " )		
		Judgment Limits	-NG/OK of B ( " )		
			OK/+NG of B ( " )		
		Corrected Instrumental Error	Correct of B (-0.9999~+0.9999)		
	Calculation Value	Judgment Limits	-NG/OK of CALC (Input actual dimensions)		
			OK/+NG of CALC ( " )		
System	External Switch Operation		External Switch	Hold <input checked="" type="checkbox"/> Not Hold <input type="checkbox"/>	
	Average Shift Frequency		Smooth Times (1~30)		
			10		

**Setting Sample in Case of Core Measurement (Above)**


## 11.2 2-Series Inside Diameter Measurement

When measuring the respective inside diameters of Channels A & B.

	ØD1	ØD2
Max. Range	14.010	14.660
Min. Range	14.000	14.650



Master (Max. & Min) for  
Channel A



Master (Max. & Min) for  
Channel B




Work Tolerance

+0.0080  
+0.0020

**Channel A: Ø14**

+0.0050  
+0.0000

**Channel B: Ø14.65**



- (1) Set the Program No. to 2.
- (2) Set the [Measuring range] to 20 $\mu$ m.
- (3) Channel A will be for the measurement of the outside diameter, so choose + for Polarity A.
- (4) Channel B will be for the measurement of the outside diameter, so choose + for Polarity B.
- (5) Select NO USE in the [CALC Function].
- (6) Choose EACH in the [Master set way].
- (7) Input the minimum (range) master value (14.0000) of Channel A.
- (8) Input the maximum (range) master value (14.0100) of Channel A.
- (9) Input the -NG/OK limits (14.0020 (=14+00.20)) of Channel A.
- (10) Input the OK/+NG limits (14.0080 (=14+00.80)) of Channel A.
- (11) Input the corrected instrumental error (+0.0000) of Channel A.
- (12) Input the minimum (range) master value (14.6500) of Channel B.
- (13) Input the maximum (range) master value (14.6600) of Channel B.
- (14) Input the -NG/OK limits (14.6500 (=14.65+0.0000)) of Channel B.
- (15) Input the OK/+NG limits (14.6600 (=14.65+0.0050)) of Channel B.
- (16) Input the corrected instrumental error (+0.0000) of Channel B.
- (17) Select [WRITE] in the [Store set value].

Setting complete. Commence with the measurement after performing master setting

Setting Mode	Setting Item		Model	DAG2200	
			Prog. No.	[2]	
Detail	Measuring Range		Measuring Range		
	Resolution		Resolution		
	Channel A	Polarity	Polarity of A	+ -	
			Polarity of B	+ -	
	Calculation Method		CALC Function (Input calculation method)		
	Master Setting Method		Master set way	ALL EACH	
				✓	
Normal	Channel A	Min. Master	MIN. M. of A (Input actual dimensions)		
		Max. Master	MAX M. of A ( " )		
		Judgment Limits	-NG/OK of A ( " )		
		Corrected Instrumental Error	OK/+NG of A ( " )		
		Correct of A (-0.9999~+0.9999)	0.0000		
	Channel B	Min. Master	MIN. M. of B (Input actual dimensions)		
		Max. Master	MAX M. of B ( " )		
		Judgment Limits	-NG/OK of B ( " )		
		Corrected Instrumental Error	OK/+NG of B ( " )		
		Correct of B (-0.9999~+0.9999)	0.0000		
System	External Switch Operation	Judgment Limits	-NG/OK of CALC (Input actual dimensions)		
			OK/+NG of CALC ( " )		
	Average Shift Frequency		Smooth Times (1~30)		
			10		

Setting Sample in Case of 2 Inside Diameter Measurement (Above)

## Chapter 12 Maintenance

- (1) Use alcohol to remove the dirt from the main body of the product.  
Using thinner may cause fading of the color product or may produce dirt.
- (2) The filter will get clogged when used for a long period of time.  
Change the element 2 years after the start of use of the filter, or when the pressure has dropped to 0.1 MPa.
- (3) Cleaning the A/E Converter  
Oil and dirt may adhere inside the air circuit when the product is used for a long period of time.  
Clean the product through the following procedure.  
When there is too much oil, we recommend using a pressurized air cleaner.
  - ① Record the position (distance from the main body to the edge) of the zero position/sensitivity regulator knob.  
After cleaning, the master setting process will be easier.
  - ② Turn the zero position/sensitivity regulation knob counterclockwise and then pull it and remove it from the main body.
  - ③ Inspect the O-ring of the needle. When it is already damaged, replace it.
  - ④ Clean the needle if it is dirty.  
Clean the hole part (ø13) that is hit by the needle with the use of a cotton swab with alcohol.
  - ⑤ Assemble the needle into the main body of the product.  
If the screw looks loose, use a – screwdriver to tighten it.  
Be careful so that the screw will not be excessively tightened.
  - ⑥ Turn the needle clockwise and then assemble it into the position that was recorded at the beginning of the cleaning process.  
Adjust with the use of the zero position/sensitivity regulation knob, and perform master setting.


## Chapter 13 Troubleshooting

Phenomenon	Breakdown Point or Place with Defective Regulation	Countermeasure
The precision when the product is used repeatedly does not become stable	<ul style="list-style-type: none"> <li>① The supplied pressure is not stable</li> <li>② Defective regulator functions</li> <li>③ The nozzle is worn out</li> <li>④ There is air leak in the pipes, couplers, etc.</li> <li>⑤ Oil has penetrated the main body</li> </ul>	<ul style="list-style-type: none"> <li>① Set the source pressure of the regulator to more than 300kPa</li> <li>② Overhaul or change the regulator</li> <li>③ Change the nozzle with a new nozzle</li> <li>④ Check the leak and re-tighten</li> <li>⑤ Clean the main body (use the pressurized air cleaner)</li> </ul>
The zero position regulator dial is not working	<ul style="list-style-type: none"> <li>① The supplied pressure is not low or high</li> <li>② Defective regulator functions</li> <li>③ Nozzle clearance is too small</li> <li>④ Nozzle clearance is too big</li> </ul>	<ul style="list-style-type: none"> <li>① Set the regulator pressure to 196kPa</li> <li>② Check the leak and re-tighten</li> <li>③④ Adjust the clearance to the proper clearance</li> </ul>
The main display is not moving	<ul style="list-style-type: none"> <li>① The correct power supply is not supplied</li> <li>② Defective zero position regulation</li> <li>③ The measurement values are on hold. Indicator is green (dark) or red (dark)</li> <li>④ The unit is in the Measurement mode</li> </ul>	<ul style="list-style-type: none"> <li>① Supply the unit with AC85-264V</li> <li>② Adjust the master</li> <li>③ Cancel or erase with the <b>RST</b> button</li> <li>④ End the Measurement mode</li> </ul>
The indicators do not light up	<ul style="list-style-type: none"> <li>① No power</li> <li>② Busted fuse</li> <li>③ Broken power supply/internal circuit</li> </ul>	<ul style="list-style-type: none"> <li>① Supply the unit with AC85-264V</li> <li>② Change the fuse (3A)</li> <li>③ Send the unit to the manufacturer for repairs</li> </ul>

## Chapter 14 Others

### 14.1 Model

**DAG 22 00 - H - DP - P - R**



## 14.2 Options

### 14.3 Specifications

Item	Specification		Remarks
Input Module		Air 2-channel	
Number of Programs		10	
Master Setting		Minimum, Maximum	
Automatic Master Setting Range	Zero Correction	Within Measurement Range ±50%	
	Sensitivity Correction	Within Measurement Range ±20%, or 0.5~2.0 times	
Main Display		30-dot color bar (red, green orange, light and dark) <LED Bar> 4-digit digital display (red, green, orange, light and dark) <7-segment LED>	Measurement value, calculation results and general judgment
LCD Display		16 * 2-character liquid crystal display	
Number of Setting Items		3	Measurement 2, Calculation 1
General Judgment Lamp		OK/Green LED, NG/Red LED	
Range [μm]		50, 100	Common in ITEM 1, ITEM 2, CALC
Resolution [μm] (Main Display Digital Values)		5, 2, 1, 0.5, 0.2, 0.1	Common in ITEM 1, ITEM 2, CALC
Power Supply	Voltage	AC85~264V	Comes with cable for AC100V
	Frequency	50/60Hz (common)	
	Capacity	40VA	
Regulator	Type	External	
	Supply Pressure	0.3~0.7MPa	
Weight (kg)		3	3.5 (When installing the regulator)
Dimensions (W x D x H) [mm]		150 x 180 x 193	D275 (When installing the regulator)
Working Temperature		0~45°	
Standard I/F		RS-232C, 1 port	Measurement values and judgment results output
		Push-button and foot switch input	Measurement command, RESET, master setting

Calculation Method		NO USE, A-B, A+B, (A+B)/2, B-A, (A-B)/2, (B-A)/2	Select 1
Options	High-Precision Measurement	Measurement range 10μm	Choose 1
		Measurement range 20μm	
	Wide-Range Measurement	Measurement range 200μm	
	Digimatic Output	1 port	Comes with DP-1 cable
	Judgment, BCD and Rank Output	Input Signals: 8	Measurement command, RESET, master setting and program change/switch
		Output Signals: 24	Ready and Master OK
			1. Judgment (Rank) output, 2. BCD output, 3. Rank output
	Foot Switch	Single	Measurement command
		Dual	Measurement command, RESET
	Serial Communication Function	RS-232C	
	Peak Measurement Function	+PEAK, -PEAK, TIR(=+PEAK-(-PEAK)), TIR/2(=+PEAK-(-PEAK)/2))	Comes with automatic measurement function due to the measurement changes
	Rank Expansion Function	Maximum of 99 ranks	OK range
	Master Setting Function for Special Measurements		
	Regulator		Precision regulator
	Filter	Manual Drain	
		Auto-Drain	
	Compressed Air Cleaner		When there is too much water and oil

Chapter 15 Worksheet

		Judgment Limits	-NG/OK of B ( “ ” )									
			OK/+NG of B ( “ ” )									
	Corrected Instrumental Error	Correct of B (-0.9999~+0.9999)										
	Calculation Value	Judgment Limits	-NG/OK of CALC (Input actual dimensions)									
			OK/+NG of CALC ( “ ” )									
	System	External Switch Operation	External Switch	Hold								
				Not Hold								
		Average Shift Frequency	Smooth Times (1~30)									



## Warranty

After purchasing, fill in the product model, serial number, date of purchase, and customer information and keep it in a safe place.

<b>① Model number</b>	
<b>② Serial number</b>	
<b>③ Purchased date (yyyy/mm/dd)</b>	
<b>⑥ Customer</b>	<b>Company name or name of purchaser</b> ..... <b>Address</b> ..... <b>TEL:</b> <b>FAX:</b>

**⑤ Warranty period**  
from purchased date

**One year**

### Warranty regulations

During the warranty period, we will repair the product at free of charge only in case of failure that occurs at our responsibility.

Please present or attach this warranty sheet when requesting no charge repair.

- The product warranty area is limited within Japan.
- The warranty covers only the purchased product itself.

The following costs and damages are not covered by the warranty

- 1) Transportation costs associated with this product
- 2) Cost of removal, installation and other incidental work when the product is connected to or incorporated in another device.
- 3) Consequential damage to the user due to a failure of this product, such as loss of usage opportunities and/or downtime of the operation
- 4) Any other consequential or incidental damage.

There is a charge for repairs caused by the following cases

- 1) In case of using under undesignated operational conditions such as with the special regulator specifications, the special air supply piping and etc. In case of using under the operational circumstances such as a high temperature/high humidity, near magnetic field, and improper supply air conditions.
- 2) Failure caused by the equipment systems where the product is built-in.
- 3) In case of modification or repair by the other company.
- 4) In case of natural disaster, fire, abnormal voltage, etc.
- 5) Failure caused by improper handling not following the cautions in the operation manual or failure caused by insufficient maintenance.
- 6) In case of a consumable part is deteriorated and needs to be replaced.

※ Repair support period for measuring and control devices  
The measuring and control devices can be repairable within a period of 3 years from the date of discontinuation.

The major spare parts for repairs are also available in the same period.  
Electronic parts may have some difficulties for procurement and production due to its short life cycle.

Please note repair may not be possible even during the period.

※ Repair request  
Please contact your local distributor for repair requests.



**SKS** CORPORATION

3-11-8 Sakuramori, Yamato City, Kanagawa 242-0028 Japan  
PHONE +81-46-240-7350 FAXSIMILE +81-46-240-7384





**SKS** CORPORATION

---

Kanagawa Head Office & Technical Center

3-11-8 Sakuramori, Yamato-City, Kanagawa 242-0028 Japan

PHONE: +81-46-240-7350 FAX: +81-46-240-7384

HEADQUARTERS

1-2-2 Higashikamata, Ota-Ku, Tokyo 144-0031 Japan

PHONE: +81-3-3734-8411 FAX: +81-3-5744-3241