

Column Type AIR MICROMETER

CAG4000-1CH**Instruction Manual**

Thank you for your purchasing of
CAG-4000-1CH

- Please read this instructions thoroughly and well understand for safety use of the unit.
- After reading, please always put and use this instructions at your hand.
- Specifications may be changed without prior notification. Please ask our company for details.

No duplication or no transfer is allowed without our permission

Prior notices to usage

- Surely obey "Precautions for Safety" to prevent from fire, electric shock, and injury
- After reading, please be sure to keep it where you can always use it.
- If lending to another person, please hand it along with the instruction manual.
- **Warranty**

Based on our warranty policy.

- Even within a term of warranty, we will ask for repair cost if malfunctions or damages are apparently attributed to causes from handling of a customer.
 - We may not accept repair work if malfunctions or damages are caused from modifications or changes by a customer.
 - Repair work shall be performed by being sent back the unit to our company.
- Even within a term of warranty, if repair work would be requested at site, we will ask for expenses for business trip.

Contents

1 . Precautions for Safety	2
2 . Overview	4
• Specification	4
• Model type	8
• Standard accessory	8
3 . Part names and functions	9
4 . Installing the unit	1 6
5 . Turning the power on/off	1 7
6 . Operation procedures	1 8
7 . Setting procedures	2 3
• Switching program	2 3
• Entering setting values	2 4
8 . Adjustments	3 7
• Adjusting ZERO/MAG	3 7
• For Inner diameter measurement	3 9
• For Outer diameter measurement	4 2
9 . External input/output	4 5
• RS232C	4 5
• External buttons input	6 0
1 0 . Setting list	6 3

1 . Precautions for Safety

Before use, read "Precautions for Safety" thoroughly and follow directions, then use correctly.

Warning indications

Precautions are classified into following three



- Precaution for possibility of getting death or serious injury if a user misuse the unit



- Precaution for possibility of getting serious injury if a user misuse the unit



- Please be aware that if you handle it incorrectly, it may result in machine damage.



In addition, even matters assigned with a "Caution" level box, possibility of a serious result may be caused, so that surely obey described every precaution for safety



- Do not modify or dismantle the unit.
If a person who does not have enough knowledge on the unit modifies or dismantles, not only insufficient performance but also fire, electric shock or an injury may be caused.
- Do not repair the unit by yourself.
If a person who does not have enough knowledge on the unit repairs, not only insufficient performance but also fire, electric shock or an injury may be caused.
- Use the power supply at the voltage described in the instruction manual.
Failure to use the specified voltage may cause a fire or electric shock.
This unit is compatible with DC 9 to 12 V
An external ac adapter (standard accessory) is for 100 - 240vac
- Remove the power cable from the main body when conducting air connection, installation or move. If the power cable is not removed, an electric shock may occur

- Surely install a grounding wire, if it is not installed, an electric shock may be caused when malfunction or a leak current occurs.
- Put the power plug into the power outlet securely, if it is unsuccessfully inserted that may cause fire or an electric shock.
- Do not use a damaged cable or a plug, it may cause fire or an electric shock
- Check the power cable periodically, if it is damaged, never use it. The damaged cable may cause fire or an electric shock.
- When an expansion cord is used, check it periodically if it is damaged, do not use it. The damaged cable may cause fire or an electric shock.
- Make sure that the power switch is "off" before putting the power plug into the power outlet. If the power switch is "on", an electric shock may occur.
- Do not use the power cable when taking the power plug off from the power outlet. If the power cable is used, it is damaged and it may cause fire or an electric shock.
- Do not place the power cable close to heat, oil or a sharp corner, if the power cable is damaged, it may cause fire or an electric shock.
- Clean the dust on the power plug periodically, if dust accumulates, that may cause fire or an electric shock.
- Take the cable off from the main body when cleaning. If the cable is put on, an electric shock may occur.
- Take the power plug off from the power outlet when you don't use the unit for a long time. If you do not do so, deterioration may cause fire or an electric shock.
- Do not use the unit in the condition of much humidity or water. Electric leakage, fire or an electric shock may occur.

- 17 . Do not use the unit at unstable place.
If the main body topples down or falls, resulting in giving a shock that may cause a malfunction. If such situation occurs, please contact us
- 18 . Do not put foreign matters into the main body. If the foreign matters such as conductive matters enter into gap of the unit may cause a malfunction.
- 19 . Do not use chemical agent such as benzene or thinner for cleaning, they may cause discoloration.

Important

- 1 . Be care not to put seal materials into pipe when plumbing.
- 2 . Make sure a label on each port and then make correct plumbing
- 3 . Attach an air filter
- 4 . Periodical maintenance should be made on the air filter
- 5 . Before supplying the air, make sure not to cause an accident on an out port side device.
- 6 . Conduct daily inspections and regular inspections in a planned manner.

- 7 . When the power cable has 3P i.e. a grounding wire is attached, surely connect the grounding wire.
- 8 . This instruction manual does not describe all functions.

Features not listed are prepared separately.

Contact us about you want to know functions.

Contact: Sales management section in Kanagawa

2 . Overview

Specification

1
4

Item	Specifications					Notes					
Product Name	Column Type Air Micrometer										
Model	CA G 40 xx -1 CH										
Specifications											
A/E Converter											
Number of loading	1										
specification	AE 21 xx S DA										
Range [μ m]	10	20	50	100	200	When ordering Specify the measurement range. The setting changeable range differs depending on the specified measurement range. Note 1					
10	H OPTION	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>					
20	M OPTION	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>					
50		<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>					
100		<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>					
200	W OPTION	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>					
Connection	Takeno nipple					For inner diameter φ4 polyurethane tube					
display											
BAR LED	101dot Color LED										
LCD	Touch Screen No function										
size	2" TFT LCD										
resolution	240 x 320										
Setting											
Number of programs	30										
MENU Display language	English, Japanese, Chinese					Changeable in settings					
Change the settings	Change in CAG										
External editing	Change in PC					Changed by via SD card Separate document					
Master											
MASTER Adjustment	ZERO/MAG										
Master alignment method	Small Master /Large Master					Dedicated button Note 2					
Small Master alignment	$\pm 50\%$ (Range)										
Large Master alignment range	$\pm 20\%$ (Range)										
	0.5 ~ 2.0 within										
Special master	OPTION	Small/Large Master Change									
		Pitch measurement									

Note 1 . About measurement range for A/E converter

- ① Measurement range needs to be specified at the time of shipment from the factory.
 - FS.200 μ m is a dedicated machine.
- ② If you want to change the measurement range of the A / E converter already in use
We need to return the CAG4000 to our factory.

Note 2 . About Master calibration

- According to usage situation of measurement tools;
Adjustment for ZERO/MAG adjuster of A/E converter may be needed.

2 . Overview

Specification

2
4

Item	Specifications					Notes
Measurement						
Number of items	1					
range [μm]	10	20	50	100	200	Note 3
Instruction range [μm]	8	16	40	80	160	
resolution [μm]	0.1 / 1 Select			1		
Measurement standard	real time					Note 4
Peak function OPTION						
Measurement P	maximum minimum maximum - minimum (maximum - minimum) / 2 (maximum + minimum) / 2 maximum & minimum					Function to temporarily hold the maximum and minimum values during measurement
Stabilization time [SEC]	0.0 ~ 9.0					A stable time until the start of measurement
Start measurement [%]	± 50 ~ 95					
Measurement time [SEC]	0.1 ~ 99.9, ∞					Time from start of measurement to completion of measurement
Post processing	Hold Reset					Processing after measurement completion
Measurement						
correction standard						Posted in a separate document
Judgment standard	OK NG	-NG	OK	-NG		
Rank OPTION	OK 3 Rank	-NG	-OK	OK	+OK	-NG
	R OK 99 Rank	-NG	R01 R02 ... R98 R99	-NG		

Note 3 . Measurement range


- Change for setting makes measurement range selectable.
- The selection range of the measurement range depends on the measurement range of the A / E converter at shipment.

Note 4 . Measurement function

- Only real time mode is standard
- When the peak measurement function (option) is included, other measurement functions can be selected by setting.

Note 5 . Judgment function

- Judgment for -NG/OK/+NG is only equipped as standard.
- When the rank judgment function (option) is attached, the OK range can be subdivided and judgment can be made.



2 . Overview

Specification

3
4

Item	Specifications		Notes
Save measurement results			
Storage location	SDCard		Note 6
Supported SD Card Types	SD Card(~ 2GB) <input type="radio"/> SDHC Card(4GB ~ 32GB) <input type="radio"/> SDXC Card(64GB ~) <input checked="" type="radio"/>	  	It does not correspond to the capacity more than DXC card The SD card purchased by the customer is not covered by the operation guarantee. When used It is recommended to use it after performing sufficient operation check.
file organization	Every program		One file configuration can be selected daily / monthly
Saved contents	CSV file format		Storage data is date and time, measured value, judgment
Save timing	Save when holding measurement value		Note 7
Data deletion function	None		
External input / output			
RS232C	standard	1 port	Output measured value and judgment
USB 2.0	standard	1 port	For PC connection (Virtual COM port connection) Note 8
External switch input	standard	DRY contact input 4 points (MAS/RESET/MIN/MAX)	For push button / foot switch connection
Continuous data output	RD	(CONT/RESET/MIN/MAX)	Specification is required at the time of factory shipment
Digimatic output	OPTION	1 port	
printer	DP	Dedicated cable option	
U-WAVE	uw	Dedicated cable option	
DCInput and output	OPTION		Specification is required at the time of factory shipment
Judgment output	DC	Judgment(-NG/OK/+NG)	
BCD output	BC	Output measured value	
Rank output	DR	Judgment(-NG/Rank/+NG)	It is necessary to use in combination with the rank judgment function
DC program switching	PK	Program switching is possible	PROG[01] ~ [16]

Note 6 . Storage location of measurement results

- Backup should be performed once a week periodically by data saving.

Note 7 . Timing of saving measurement results

- Measurement → Save when measured measurement value changes.
- Real time data saving during measurement is impossible.

Note 8 . USB

- impossible to connect with a PLC or so on.
- A driver should be installed before connection to a PC.

2 . Overview

Specification

4
4

Item	Specifications		Notes	
usage environment				
Operating temperature	5 - 40 [°C]			
Power supply	DC 9-12[V],2[A]		Dedicated AC adapter included	
Dedicated AC adapter				
Power supply	AC100-240[V],50/60[Hz]			
Plug	A2			
Supply air pressure	0.3 - 0.7	[MPa]	Clean dry air (no water or oil) Note 9	
Air supply amount	50 / 60	[L/min]	60 [L / min] for a range of 200 µm	
External dimensions(WxDxH)	width	Depth	High	
Single type	50 x 131 x 480	[mm]	Stand,Regulator uneven part not included	
	170 x 291 x 480	[mm]	Stand,Regulator uneven part not included	
weight			Excluding accessories	
Display	3.5 [kg]			

Note 9 . Air supply source

- Supply filtered air with less than 0.3µm filter element.
- If the supply air source contains water or oil, install a water removal / oil removal filter on the front.

2 . Overview

Model type

Note A telop shows at power on.
A part of description differs from model type described on the catalogue.

The diagram shows the model type code structure: CAG 40 XX - 1 CH - [P] - [R] - [SD] - [DC] - [DP] - [S] - [] - [] - [RD]. The first four positions (CAG, 40, XX) are fixed. The fifth position (1) indicates 1 channel. The following seven positions are optional and represented by brackets. The last two positions (RD) indicate continuous data output (RS232C).


item	symbol	内容	
option		No option	
	P	Peak measurement function	
	R	Rank judgment function	
	SD	Measurement result save function	
	DC	Judgment output	
	BC	BCD output	
	DR	Rank output	
	PK	DC program switching	
	DP	Digimatic output There is no difference between printer and U-WAVE	
	S	Special master alignment	
A / E	1	1 channel	
range factory shipment Initial setting	H	10 20 50 100	μm
	M	20 50 100	μm
		50 100	μm
	W	200	μm designated
range Shipping settings	01	10	μm
	02	20	μm
	05	50	μm
	10	100	μm
	20	200	μm
Series name	40		
Model	CAG	Column Type Air Gage	

Accessories [Standard]

- AC adapter


3 . Part names and functions

Front view




3 . Part names and functions

Rear view



3 . Part names and functions

Side view



13 Precision regulator

- actory air source to IN port, supply clean dry air with 0.3-0.7MPa.
- Available to connect a polyurethane tube with φ8.
- Stable pressured air is supplied to an A/E converter.
- Never make adjustments. **Important**
The pressure has been adjusted.
- If mishandled, quit using **Important** the unit.

3 . Part names and functions

Details of LCD display


1	Mode display	Display the current mode and status.	2	measured value	Display the measured value.																								
	<table border="1"> <thead> <tr> <th>icon</th><th>Operating mode and status</th></tr> </thead> <tbody> <tr> <td></td><td>White: Measurement</td></tr> <tr> <td></td><td>White: Setting Yellow: System setting</td></tr> <tr> <td></td><td>White: Master Red: Master NG</td></tr> <tr> <td></td><td>White: Program change Red: SD card error</td></tr> <tr> <td></td><td>Error condition</td></tr> <tr> <td></td><td>White: Measurement value retention</td></tr> </tbody> </table>	icon	Operating mode and status		White: Measurement		White: Setting Yellow: System setting		White: Master Red: Master NG		White: Program change Red: SD card error		Error condition		White: Measurement value retention		4	Judgment result and master matching status	<table border="1"> <thead> <tr> <th>display</th><th></th></tr> </thead> <tbody> <tr> <td>+NG</td><td>Judgment“+NG”</td></tr> <tr> <td>OK</td><td>Judgment“OK”</td></tr> <tr> <td>-NG</td><td>Judgment“-NG”</td></tr> <tr> <td>CAL</td><td>Master set request → Please do the master set</td></tr> </tbody> </table>	display		+NG	Judgment“+NG”	OK	Judgment“OK”	-NG	Judgment“-NG”	CAL	Master set request → Please do the master set
icon	Operating mode and status																												
	White: Measurement																												
	White: Setting Yellow: System setting																												
	White: Master Red: Master NG																												
	White: Program change Red: SD card error																												
	Error condition																												
	White: Measurement value retention																												
display																													
+NG	Judgment“+NG”																												
OK	Judgment“OK”																												
-NG	Judgment“-NG”																												
CAL	Master set request → Please do the master set																												
3	Display value	Displays what the measured value is	5	Display unit	Displays the display unit of the measured value.																								
	<table border="1"> <thead> <tr> <th>icon</th><th></th></tr> </thead> <tbody> <tr> <td></td><td>real time</td></tr> </tbody> </table>	icon			real time		8	Measurement range	Displays the measurement range.																				
icon																													
	real time																												
6	Program number	Displays the current program number.																											
7	State of measurement																												
	<table border="1"> <thead> <tr> <th>Display</th><th></th></tr> </thead> <tbody> <tr> <td>W</td><td>During stable time operation</td></tr> <tr> <td>M</td><td>Measurement time in operation</td></tr> <tr> <td>R</td><td>During continuous data output</td></tr> <tr> <td>R</td><td>During continuous data output</td></tr> </tbody> </table>	Display		W	During stable time operation	M	Measurement time in operation	R	During continuous data output	R	During continuous data output																		
Display																													
W	During stable time operation																												
M	Measurement time in operation																												
R	During continuous data output																												
R	During continuous data output																												

3 . Part names and functions


Panel switches

Switch Name / Operation Screen	Key operation	State
1 Left arrow key  SET		
1 Measurement screen	2 seconds	Switch to setting screen
2 Right arrow key  MAS		
1 Measurement screen	2 seconds	Switch to master set screen
3 Master set screen	Once	Switching display content
3 Reset key RST		
1 Measurement screen (Measured value hold)	Once	Release hold
3.1 Master set screen	Once	Revert to the previous state
3.2 Adjustment screen	Once	Revert to the previous state
5 Settings screen (Set value input)	Once	Revert to the previous state
5 Settings screen (Item selection)	Once	Finish setting(WRITE/CANCEL)
6 Enter key ENT		
1 Measurement screen	Once	Hold the measured value (In the case of master OK)
3.1 Master set screen	Once	Read master value
3.2 Adjustment screen	Once	End of detector adjustment
5 Settings screen	Once	Setting decision
5 Up arrow key  SYS		
1 Measurement screen	2 seconds	Switch to system mode
5 Settings screen	Once	Input of setting value
8 Large master key MAX M.		
1 Measurement screen	Once	Large master setting
4 Down arrow key  PROG		
1 Measurement screen	2 seconds	Program switching mode
5 Settings screen	Once	Input of setting value
7 Small master key MIN M.		
1 Measurement screen	Once	Small mastersetting

3 . Part names and function



3 . Part names and functions



4 . Installing the unit

Installing main body

Important

- Install the main body on the flat and stable place without vibration.
- Install the filter parts lower than the main unit.

Connecting AC adaptor

Follow below steps to connect the ac adaptor.

- 1 Turn off the power switch



- 2 Connect the ac adaptor to the power connector




- 3 Put the power plug of ac adaptor into the power outlet.



Connect the air tube

⚠ Warning

- Connect the air hose while the power is turned "off".



- 1 Turn off the power switch



- 2 Connect the air hose from measurement tool to the GAGE port



- 3 Connect the air tube from the filter to the precision regulator.

5 . Turning the power on/ off

Turning the power “on”

- 1 Make sure that the AC adapter's power plug is fully inserted into the power outlet.

- 2 Turn the power switch “on”




- 3 Display the startup screen.



Turning the power “off”.

- 1 Turn the power switch off



- 2 Take the power plug of the ac adaptor off from the power outlet.

6 . Operation procedures

Preparing before measurement

Important

- Air micrometer is a comparison type measurement device.
- Accuracy is not guaranteed if dirt, flaw, dent, or rust exists on the master and measurement tools
- Connectable measuring tool
- Connection to other company's measurement tools is out of guarantee for accuracy
- If specs of the measurement tools to be connected and that of the main body (measurement range) are not in conformance to, they may not connect with each other.
- Air micro is vulnerable to water and oil.
 - If water or oil invades into the air micrometer The following symptoms occur.
 - Impossible for master calibration
 - Impossible to adjust ZERO/MAG adjuster.
 - The same value does not appear even if the same workpiece is measured
 - The indicated value becomes unstable
 - Accuracy will be worse
 - To suppress above symptoms is periodical replacement of a filter element.
 - If water or oil invades, immediate quit using, and repair or overhaul is recommended.

1 • Check the filter


Is there no water or oil buildup

2 • Check the measuring tool and the master.

Are there any dirt, scratches, dents, rust?

3

Turn "on" the compressed air and the power.



4

After a startup screen appears, and then "CAL" is displayed on the measurement screen.

Perform the master calibration.



6 . Operation procedures

Calibrating to the master



Important

- Perform master calibration with use of Min and Max masters.
- Master and measurement tool
Make sure that no flaw and dust on the master and measurement tool.

1



Please keep pressing for more than 2 seconds.

A Min master screen appears



2

Set a Min master to the measurement tool.

Numeric indication and bar color are

- “Green” :
Min master calibration is possible
- “Red” :
Min master calibration is impossible
→ Perform ZERO/MAG adjustment.



- Be sure to perform master calibration in the following cases.
 - When the power and supply air are turned “on”
 - When replacing the measuring tool
 - Two to four hours have passed after use.
 - An indication value is shown wrong.

3



Please press it.

Min master calibration is performed and then Max master calibration screen appears.



4

Set a Max master to the measurement tool.

Numeric indication and bar color are

- “Green” :
Max master calibration is possible
- “Red” :
Max master calibration is impossible
→ Perform ZERO/MAG adjustment.



6 . Operation procedures

Calibrating to the master

5

ENT

Please press it.

Performs the Max master calibration and then displays its results

6

Display of master alignment result

1 Master calibration OK



Master calibration successfully completes.

The measurement screen is displayed.


3 Sensitivity NG



It is a master set matching NG.

Go to master calibration error processing.

2 ZERO NG (failed)



It is a small master match NG.

Go to master calibration error processing.

4 Master reverse NG (failed)



Min master and Max master seem to be crossing

Go to master calibration error processing.

6 . Operation procedures

Master calibration error processing



When an error occurs

Check and take actions followings;

- Is supplying air correct?
- Don't you misuse between the Min master and the Max master?
- Are there any dirt, flaw, dent or rust on the measurement tool and master?
- In case of exception above, go to 8 adjustment.

6 . Operation procedures

Measurement




Performs work measurement.

Important

- To keep measurement accuracy,
perform the master calibration every two-hour.

- 1 Set a work (objective to be measured)
on the measurement tool

- 2 Measured value and judged result are
displayed
Indication color of "BAR LED" is
"Green" Within OK range.
"Red": Out of Ok range.



Hold measured values
and output



Holds measured values and outputs to RS232C


Important

- When master calibration is NG,
to hold measured values and
to output cannot be performed.


- 1 In state of mode as this
press the **ENT** key.

Thus the measured values are held
and this figure that shows
holding state is displayed.

Measured values and judged results are
outputted to RS232C.



- 2 Press an **RST** button, then
this figure disappears.



7 . Setting procedures

Switching program


Setting values are switched to newly entering program.

Important

- If you want to change the, setting for currently using program follow next procedures "Entering setting values".

1 Turn the power "on".

After a startup screen appears, then



2 Press  button for two seconds more, a program switching screen is displayed.

Current program No. in an upper box and newly entering program No. in a lower box are displayed.



3 Select program No. with  and  buttons.

SYS PROG



4 Press  button.

Switches to selected program and the measurement screen is displayed.



7 . Setting procedures

Entering setting values



1
13

Enter setting values for new measurement tool.

Measurement conditions can be registered up to 30 kinds.

Important

● Optional addition of measurement range

- Customer selectable measurement range is determined by designating measurement range at an order
- After delivery
The optional addition is modified at the factory in way of sending back the unit.
- Measurement range for 200μm works on an exclusive unit, so that no other measurement range can be selected.

● Setting mode

The setting mode consists of two screens such as a screen for selecting item as [Setting items] and for entering values as [Setting values].

● How to select setting item



Multiple pages

About setting items;

“Selection” is handled with

and buttons.

“Decision” is made with button.

● How to enter setting values



Current value is in upper box.
Changed value is lower box.

Following is handled with each button

Move of place



Change of setting value



Decision of setting value





Cancelling setting value



7 . Setting procedures

Entering setting values



0 Switch setting mode

1 Press it more than 2 seconds



2 Change this icon, and shows setting options.

7 . Setting procedures

Entering setting values

3
13



ENGLISH



JAPANESE




CHINESE


1 Setting of polarity

Set to


1. Inner diameter measurement ... 「1. +」
2. Outer diameter measurement... 「2. -」



1 Press ENT
Shows current setting value.



2 Enter new setting value.
Select with
/ and /
SYS PROG



3 Press ENT
Following setting items are displayed in state of being selected.

7 . Setting procedures

Entering setting values






ENGLISH

JAPANESE

CHINESE

2 Setting of measuring range



It sets measuring range

Please match with the measuring tool that is connected.

1 Press ENT

Shows current setting value.

2 Connect
Check the mark of measuring tool.

- 1 . AE2101-3
- 2 . AE2102-3
- 3 . AE2102-1
- 4 . AE2105-1
- 5 . AE2110-1
- 6 . AE2120-1

3 Enter new setting value.

Select with
/ and and

3 Press ENT

Following setting items are displayed in state of being selected.

7 . Setting procedures

Entering Setting values

5
13



ENGLISH



JAPANESE



CHINESE

3 Setting of Resolution





Set display resolution.

Below is possible to choose.

- 1) $0.1 \mu m$
- 2) $1 \mu m$

1 | Press


Current setting value is.
displayed



2 | Enter new setting value.

Select with

and



3 | Establish the setting value.

Press

Following setting items are
displayed in state of being
selected.

7 . Setting procedures

Entering setting values  6 / 13



ENGLISH



JAPANESE



CHINESE

4 Setting of Shift Unit

Set display unit for measurement value.


Below unit is selectable.

- 1) μm
- 2) mm

1

Press  ENT

Current setting value is displayed



2

Enter new setting value.

Select with

 and 

3

Press  ENT

Following setting items are displayed in state of being selected.



7 . Setting procedures

Entering setting Values

7
13



ENGLISH




JAPANESE



CHINESE


5 Setting of Shift Value

Set this when the measurement value is displayed in a one-side tolerance or actual measured value. If you do not use this function, set 0 (zero).




1 Press ENT

Current setting value is displayed




2 Enter new setting value.

Enter with



• When mm is used.

Move input place with



3 Press ENT

Following setting items are displayed in state of being selected.

7 . Setting procedures

Entering setting values

8
13



ENGLISH




JAPANESE



CHINESE


6 Upper Limit

Set an upper limit of the work.



1 Press ENT

Current setting value is displayed.



2 Enter new setting value.

Select with

and



3 Press ENT

Following setting items are displayed in state of being selected.

7 . Setting procedures

Entering setting values

9
13



ENGLISH



JAPANESE



CHINESE

7 Lower limit

Set a lower limit of the work.

Label	1/2
1. Polarity	
2. Range	
3. Resolution	
4. Shift Unit	
5. Shift Value	
6. +NG/ OK	
7. OK/-NG	
8. Max Master	

設定項目名	1/2
1. 極性	
2. 測定レンジ	
3. 表示分解能	
4. シフト単位	
5. シフト値	
6. 上限界値	
7. 下限界値	
8. 大範マスタ値	

設定項目名称	1/2
1. 极性	
2. 选择量程	
3. 分辨率	
4. 公差中間単位	
5. 公差中間値	
6. 上限超差値	
7. 下限超差値	
8. 上限标准件値	

1

Press

Current setting value is displayed

Label	1/2
7. OK/-NG	-40.0 μ m

設定項目名	1/2
7. 下限界値	-40.0 μ m

設定項目名称	1/2
7. 下限超差値	-40.0 μ m

2

Enter new setting value.

Select with

and

Label	1/2
1. Polarity	
2. Range	
3. Resolution	
4. Shift Unit	
5. Shift Value	
6. +NG/ OK	
7. OK/-NG	
8. Max Master	

設定項目名	1/2
1. 極性	
2. 測定レンジ	
3. 表示分解能	
4. シフト単位	
5. シフト値	
6. 上限界値	
7. 下限界値	
8. 大範マスタ値	

設定項目名称	1/2
1. 极性	
2. 选择量程	
3. 分辨率	
4. 公差中間単位	
5. 公差中間値	
6. 上限超差値	
7. 下限超差値	
8. 上限标准件値	

3

Press

Following setting items are displayed in state of being selected.

7 . Setting Procedures

Entering setting values

10
13



ENGLISH



JAPANESE



CHINESE

8 3 Max Master

Set a value for the Max master.

Label	1/2
1 . Polarity	1 . 極性
2 . Range	2 . 測定レンジ
3 . Resolution	3 . 表示分解能
4 . Shift Unit	4 . シフト単位
5 . Shift Value	5 . シフト値
6 . +NG/ OK	6 . 上限界値
7 . OK/-NG	7 . 下限界値
8 . Max Master	8 . 大範マスタ値

設定項目名	1/2
1 . 極性	1 . 极性
2 . 測定レンジ	2 . 选择量程
3 . 表示分解能	3 . 分辨率
4 . シフト単位	4 . 公差中間単位
5 . シフト値	5 . 公差中間值
6 . 上限界値	6 . 上限超差值
7 . 下限界値	7 . 下限超差值
8 . 大範マスタ値	8 . 上限标准件值

設定項目名称	1/2
1 . 极性	1 . 極性
2 . 选择量程	2 . Range
3 . 分辨率	3 . Resolution
4 . 公差中間単位	4 . Shift Unit
5 . 公差中間值	5 . Shift Value
6 . 上限超差值	6 . +NG/ OK
7 . 下限超差值	7 . OK/-NG
8 . 上限标准件值	8 . Max Master

1 Press ENT

Current setting value is displayed.

Label	1/2
8 . Max Master	25 μ m

設定項目名	1/2
8 . 大範マスタ値	25 μ m

設定項目名称	1/2
8 . 上限标准件值	25 μ m

2 Enter new setting value.

Select with
/ and /
SYS PROG

Label	2/2
9 . Min Master	
10 . Language	
11 . End	

設定項目名	2/2
9 . 小範マスタ値	
10 . Language(言語)	
11 . 終了	

設定項目名称	2/2
9 . 下限标准件值	
10 . Language(语言)	
11 . 结束	

3 Press ENT

Following setting items are displayed in state of being selected.

7 . Setting procedures

Entering setting values

11
13



ENGLISH



JAPANESE



CHINESE


9 Min Master

Set a value for the Min master.



1 Press

Current setting value is displayed.



2 Enter new setting value.

Select with

and




3 Press

Following setting items are displayed in state of being selected.

7 . Setting procedures

Entering setting values



10 Language

Set a display language



1

Press


Current setting value is displayed.



2

Enter new setting value.

Select with



and




3

Press

Following setting items are displayed in state of being selected.

7 . Setting procedures

Entering setting values



11 End (Save the settings)

Perform saving the settings.



8 . Adjustments

Adjusting ZERO/MAG adjuster



Adjustment of ZERO/MAG adjuster is required when weariness or change / setup of the measurement tool.




ENGLISH



JAPANESE



CHINESE




0 Switches to an adjustment screen

1 Continue to press this button for two seconds more.



2 Displays small master calibration screen.



3 Press this button.

4 Adjustment
Displays 1. Adjustment screen.

8 . Adjustments


Adjusting ZERO/MAG adjuster



Adjustment of ZERO/MAG adjuster is required when weariness or change / setup of the measurement tool.





ENGLISH



JAPANESE





CHINESE



1 Expand the display range

1 Press

The display range is expanded.



8 . Adjustments

Adjusting ZERO/MAG adjuster 3


Important

- Adjustment method is different between Inner dia and outer dia measurements.
- For inner dia measurement
 - Perform followings.
 - Zero position adjustment with Min master
 - Sensitivity adjustment with Max master
 - Go to "For Inner dia measurement".
- For outer dia measurement
 - Perform followings.
 - Zero position adjustment with Max master
 - Sensitivity adjustment with Min master
 - Go to "For Outer dia measurement"

For Inner dia measurement 1

- 2 Set the Min master to the measurement tool.


- 3 Set an indication at vicinity of the Min master value by turning ZERO adjuster



- 3 Set the Max master on the measurement tool.

Follow depending on the indication position:

- If it is at vicinity of Max master value, adjustment completes.
- If it is smaller than the Max master value, go to step 4 Shortage of sensitivity.
- If it is larger than the Max master value, go to step 5 Over sensitivity.




8 . Adjustments

For Inner dia measurement




4 Shortage of sensitivity

- 1 Set the Max master on the measurement tool, and then turn the MAG adjuster in direction of CW till the indication becomes approx. five times to the Max master value + amount of minus.
- 2 Conform the indication with close to the Max master value by turning a ZERO adjuster in direction of CW.



Please put the Max master on the tool, and check a shorgate

※It doesn't display the bar. It is just a image



- 3 Set the Min master on the measurement tool.

Follow depending on the indication position;

- 1 If it is close to the Min master value.

Adjustment is complete.

- ① Press **ENT**

Displays the Min master calibration screen.

- ② Go to 6 Operation procedures
Go to step 2 in
"Calibration to the master".

- 2 If it is larger than the Min master value
It is a shortage of sensitivity.

- ① Conform the indicator with close to the Min master value by turning the ZERO adjuster.
- ② Go to step 1 in **4 Shortage of sensitivity**

- 3 If it is smaller than the Min master value.
It is over sensitivity.


- ① Conform the indicator with close to the Min master value by turning the ZERO adjuster
- ② Go to step 1 in **5 Over sensitivity.**

8 . Adjustments

For Inner dia measurement 

5 Over sensitivity

- 1 Set the Max master on the measurement tool, and then turn the MAG adjuster in direction of CCW till the indication becomes approx. five times to the Max master value - amount of plus.
- 2 Conform the indication with close to the Max master value by turning a ZERO adjuster in direction of CCW.



- 3 Set the Min master on the measurement tool.

Follow depending on the indication position

- 1 If it is close to the Min master value.

Adjustment is complete.

- ① Press ENT

Displays the Min master calibration screen.

- ② Go to 6 Operation procedures
Go to step 2 in Calibration to the master"

- 2 Go to step 2 in Calibration to the master"
It is a shortage of sensitivity.

- ① Conform the indicator with close to the Min master value by turning the ZERO adjuster.
- ② Go to step 1 in **4 Shortage of sensitivity.**

- 3 If it is smaller than the Min master value
It is over sensitivity.

- ① Conform the indicator with close to the Min master value by turning the ZERO adjuster.
- ② Go to step 1 in **5 Over sensitivity.**


8 . Adjustments

For Outer dia measurement




2

- Set the Max master on the measurement tool.
Conform the indication with close to Max master value by turning the ZERO adjuster.



3

- Set the Min master on the measurement tool
If the indication is;
• Pointing at close to Min master value:
 Adjustment is complete.
• If it is larger than the Min master value.
 Go to step 1 in 4 Shortage of sensitivity.
• If it is smaller than the Min master value.
 Go to step 1 in 5 Over sensitivity.




8 . Adjustments

For Outer dia measurement




4 Shortage of sensitivity

- 1 Set the Min master on the measurement tool, and then turn the MAG adjuster in direction of CW till the indication becomes approx. five times to the Min master value - amount of plus.
- 2 Conform the indication with close to the Min master value by turning a ZERO adjuster in direction of CW.



※It doesn't display the bar.
It is just a image



- 3 Set the Max master on the measurement tool.

Follow depending on the indication position;

- 1 If it is close to the Max master value.
Adjustment is complete

- ① Press ENT

Displays the Min master calibration screen

- ② Go to 6 Operation procedures
Go to step 2 in Calibration to the master"

- 2 If it is larger than the Max master value.
It is over sensitivity.

- ① Conform the indicator with close to the Max master value by turning the ZERO adjuster.

- ② Go to step 1 in 5 Over sensitivity

- 3 If it is smaller than the Max master value.
It is a shortage of sensitivity.

- ① Conform the indicator with close to the Max master value by turning the ZERO adjuster.

- ② Go to step 1 in 4 Shortage of sensitivity.


8 . Adjustments

For Outer dia measurement



5 Over sensitivity

- 1 Set the Min master on the measurement tool, and then turn the MAG adjuster in direction of CCW till the indication becomes approx. five times to the Min + amount of minus.
- 2 Conform the indication with close to the Min master value by turning a ZERO adjuster in direction of CCW.



- 3 Set the Max master on the measurement tool

Follow depending on the indication position;

- 1 If it is close to the Max master value.

Adjustment is complete

- 1 Press ENT

Displays the Min master calibration screen.

- 2 Go to 6 Operation procedures.
Go to step 2 in Calibration to the master.

- 2 If it is larger than the Max master value.

It is over sensitivity.

- 1 Conform the indicator with close to the Max master value by turning the ZERO adjuster.

- 2 Go to step 1 in 5 Over sensitivity.

- 3 If it is smaller than the Max master value.

It is a shortage of sensitivity

- 1 Conform the indicator with close to the Max master value by turning the ZERO adjuster.

- 2 Go to step 1 in 4 Shortage of sensitivity.

9 . External input/output

RS232C



1 Outline



Connecting "RS232C" connector on the CAG to an external device such as PLC with an RS232C cable, the external device can perform following command operation to the CAG.

- ① Switching program
- ② Master calibration
- ③ Measurement (outputting measured judgment)

3 Specs of communications



Communication protocol is our company original.

No	項目	
1	Protocol	Original
2	Communication data	ASCII
3	Communication method	RS-232C
4	Communication speed	9,600 bps
5	Data bit	8 bit
6	Parity	None
7	Stop bit	1 bit
8	Start bit	1 bit
9	Flow control	None

2 Connector




Name RS-232C
 Type D-SUB9P(×7)
 Screw M2.6
 Pin location

Pin No	信号名	内容
1	N.C.	Not connect
2	RxD	Receive data
3	TxD	Send data
4	N.C.	Not connect
5	GND	Ground
6	N.C.	Not connect
7	N.C.	Not connect
8	N.C.	Not connect
9	N.C.	Not connect

4 Communication method




- Important**
- When PLC send [1] Command to CAG, CAG replies [2] Response to PLC.



- Following three kinds are provided for response.
 - Normal action process
 - Abnormal action processing
 - No response

9 . External input/output

RS232C



2
15

5 Command list

1
1

No	Classification	1	Command					
			Processing content			Transmission order		
			1	2	3	4	5	6
03	Program switching	Switch to PROG No 0 1	A	0	0	1	1	CR
05		Switch to PROG No 0 2	A	0	0	2	1	CR
07		Switch to PROG No 0 3	A	0	0	3	1	CR
09		Switch to PROG No 0 4	A	0	0	4	1	CR
11		Switch to PROG No 0 5	A	0	0	5	1	CR
13		Switch to PROG No 0 6	A	0	0	6	1	CR
15		Switch to PROG No 0 7	A	0	0	7	1	CR
17		Switch to PROG No 0 8	A	0	0	8	1	CR
19		Switch to PROG No 0 9	A	0	0	9	1	CR
21		Switch to PROG No 1 0	A	0	1	0	1	CR
22		Switch to PROG No 1 1	A	0	1	1	1	CR
23		Switch to PROG No 1 2	A	0	1	2	1	CR
24		Switch to PROG No 1 3	A	0	1	3	1	CR
25		Switch to PROG No 1 4	A	0	1	4	1	CR
26		Switch to PROG No 1 5	A	0	1	5	1	CR
27		Switch to PROG No 1 6	A	0	1	6	1	CR
28		Switch to PROG No 1 7	A	0	1	7	1	CR
29		Switch to PROG No 1 8	A	0	1	8	1	CR
30		Switch to PROG No 1 9	A	0	1	9	1	CR
31		Switch to PROG No 2 0	A	0	2	0	1	CR
32		Switch to PROG No 2 1	A	0	2	1	1	CR
33		Switch to PROG No 2 2	A	0	2	2	1	CR
34		Switch to PROG No 2 3	A	0	2	3	1	CR
35		Switch to PROG No 2 4	A	0	2	4	1	CR
36		Switch to PROG No 2 5	A	0	2	5	1	CR
37		Switch to PROG No 2 6	A	0	2	6	1	CR
38		Switch to PROG No 2 7	A	0	2	7	1	CR
39		Switch to PROG No 2 8	A	0	2	8	1	CR
40		Switch to PROG No 2 9	A	0	2	9	1	CR
41		Switch to PROG No 3 0	A	0	3	0	1	CR
45	Master matching	Min master matching	N					
47		Max master matching	X					
57	Measurement	Result	D					

9 . External input/output

RS232C



3
15

6

Response list (Normal processing)

1
1

No	Classification	1 Command						Processing category	2 Response															
		Transmission order→							Transmission order→															
		1	2	3	4	5	6		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
03	Program switching	A	0	0	1	1	CR	Normal	A	0	0	1	1	1	0	1	CR	LF						
05		A	0	0	2	1	CR	Normal	A	0	0	2	1	1	0	2	CR	LF						
07		A	0	0	3	1	CR	Normal	A	0	0	3	1	1	0	3	CR	LF						
09		A	0	0	4	1	CR	Normal	A	0	0	4	1	1	0	4	CR	LF						
11		A	0	0	5	1	CR	Normal	A	0	0	5	1	1	0	5	CR	LF						
13		A	0	0	6	1	CR	Normal	A	0	0	6	1	1	0	6	CR	LF						
15		A	0	0	7	1	CR	Normal	A	0	0	7	1	1	0	7	CR	LF						
17		A	0	0	8	1	CR	Normal	A	0	0	8	1	1	0	8	CR	LF						
19		A	0	0	9	1	CR	Normal	A	0	0	9	1	1	0	9	CR	LF						
21		A	0	1	0	1	CR	Normal	A	0	1	0	1	1	1	0	CR	LF						
22		A	0	1	1	1	CR	Normal	A	0	1	1	1	1	1	1	CR	LF						
23		A	0	1	2	1	CR	Normal	A	0	1	2	1	1	1	2	CR	LF						
24		A	0	1	3	1	CR	Normal	A	0	1	3	1	1	1	3	CR	LF						
25		A	0	1	4	1	CR	Normal	A	0	1	4	1	1	1	4	CR	LF						
26		A	0	1	5	1	CR	Normal	A	0	1	5	1	1	1	5	CR	LF						
27		A	0	1	6	1	CR	Normal	A	0	1	6	1	1	1	6	CR	LF						
28		A	0	1	7	1	CR	Normal	A	0	1	7	1	1	1	7	CR	LF						
29		A	0	1	8	1	CR	Normal	A	0	1	8	1	1	1	8	CR	LF						
30		A	0	1	9	1	CR	Normal	A	0	1	9	1	1	1	9	CR	LF						
31		A	0	2	0	1	CR	Normal	A	0	2	0	1	1	2	0	CR	LF						
32		A	0	2	1	1	CR	Normal	A	0	2	1	1	1	2	1	CR	LF						
33		A	0	2	2	1	CR	Normal	A	0	2	2	1	1	2	2	CR	LF						
34		A	0	2	3	1	CR	Normal	A	0	2	3	1	1	2	3	CR	LF						
35		A	0	2	4	1	CR	Normal	A	0	2	4	1	1	2	4	CR	LF						
36		A	0	2	5	1	CR	Normal	A	0	2	5	1	1	2	5	CR	LF						
37		A	0	2	6	1	CR	Normal	A	0	2	6	1	1	2	6	CR	LF						
38		A	0	2	7	1	CR	Normal	A	0	2	7	1	1	2	7	CR	LF						
39		A	0	2	8	1	CR	Normal	A	0	2	8	1	1	2	8	CR	LF						
40		A	0	2	9	1	CR	Normal	A	0	2	9	1	1	2	9	CR	LF						
41		A	0	3	0	1	CR	Normal	A	0	3	0	1	1	3	0	CR	LF						
45	Master matching	N						Normal	@	0	E	R	R	0	4	G	A	I	N	M	1	CR	LF	
47		X						Normal	@	0	0	K	SP	SP	SP	M	A	S	SP	SP	SP	CR	LF	
57	Measurement	D						Normal	Measured value						SP	Judge	CR	LF						

9 . External input/output

RS232C



7 Details of commands

1
12

7 2 Switching program

1
9

1 Purpose

- Uses when you want to switch Program No. of CAG operation.
Just after the program switching, surely perform the master calibration.

2 Response of CAG

- When normal action processing, command + "1" + "PROG No" +CRLF is responded.
- When abnormal action processing, command + "4" + "00" +CRLF is responded.
- When status is following cases, no response is returned.
 - During startup at the power is on.
 - During continuous data from the connector "SW ETC" is outputting.
 - During performing writing measured results or reading /writing between CAG and SD Card.

3 Abnormal action processing

- When status of CAG is following cases, abnormal is responded.
- During under operation other than the measurement mode.
 - An error occurred at EEPROM reading when internal processing for Program No switching.

9 . External input/output

RS232C



5
15

7 Details of commands

2
12

7 2 Switching program

2
9

4 Command and Response list

1 Switch to PROG No. 0 1

Classification	Processing category	Transmission order→										Processing content
		1	2	3	4	5	6	7	8	9	10	
1	Command 03	A	0	0	1	1	CR					
2	Response 03	Normal	A	0	0	1	1	0	1	CR	LF	Switch complete. Operate with PROG No 01
		Abnormal	A	0	0	1	1	4	x	x	CR	LF

2 Switch to PROG No. 0 2

Classification	Processing category	Transmission order→										Processing content
		1	2	3	4	5	6	7	8	9	10	
1	Command 05	A	0	0	2	1	CR					
2	Response 05	Normal	A	0	0	2	1	1	0	2	CR	LF
		Abnormal	A	0	0	2	1	4	x	x	CR	LF
												Switch failure. Operate with PROG No xx

3 Switch to PROG No. 0 3


Classification	Processing category	Transmission order→										Processing content
		1	2	3	4	5	6	7	8	9	10	
1	Command 07	A	0	0	3	1	CR					
2	Response 07	Normal	A	0	0	3	1	1	0	3	CR	LF
		Abnormal	A	0	0	3	1	4	x	x	CR	LF
												Switch failure. Operate with PROG No xx

4 Switch to PROG No. 0 4

Classification	Processing category	Transmission order→										Processing content
		1	2	3	4	5	6	7	8	9	10	
1	Command 09	A	0	0	4	1	CR					
2	Response 09	Normal	A	0	0	4	1	1	0	4	CR	LF
		Abnormal	A	0	0	4	1	4	x	x	CR	LF
												Switch failure. Operate with PROG No xx

9 . External input/output

RS232C



6
15

7 Details of commands

3
12

7 2 Switching program

3
9

4 Command and Response list

5 Switch to PROG No. 0 5

Classification		Processing category	Transmission order→										Processing content
1	2		3	4	5	6	7	8	9	10			
1	Command	11		A	0	0	5	1	CR				
2	Response	11	Normal	A	0	0	5	1	1	0	5	CR	LF
			Abnormal	A	0	0	5	1	4	x	x	CR	LF

Switch complete. Operate with PROG No 05
Switch failure. Operate with PROG No xx

6 Switch to PROG No. 0 6

Classification		Processing category	Transmission order→										Processing content
1	2		3	4	5	6	7	8	9	10			
1	Command	13		A	0	0	6	1	CR				
2	Response	13	Normal	A	0	0	6	1	1	0	6	CR	LF
			Abnormal	A	0	0	6	1	4	x	x	CR	LF

Switch complete. Operate with PROG No 06
Switch failure. Operate with PROG No xx

7 Switch to PROG No. 0 7

Classification		Processing category	Transmission order→										Processing content
1	2		3	4	5	6	7	8	9	10			
1	Command	15		A	0	0	7	1	CR				
2	Response	15	Normal	A	0	0	7	1	1	0	7	CR	LF
			Abnormal	A	0	0	7	1	4	x	x	CR	LF

Switch complete. Operate with PROG No 07
Switch failure. Operate with PROG No xx

8 Switch to PROG No. 0 8

Classification		Processing category	Transmission order→										Processing content
1	2		3	4	5	6	7	8	9	10			
1	Command	17		A	0	0	8	1	CR				
2	Response	17	Normal	A	0	0	8	1	1	0	8	CR	LF
			Abnormal	A	0	0	8	1	4	x	x	CR	LF

Switch complete. Operate with PROG No 08
Switch failure. Operate with PROG No xx

9 . External input/output

RS232C



7 Details of commands



7 2 Switching program



4 Command and Response list

9 Switch to PROG No. 0 9

Classification		Processing category	Transmission order→										Processing content	
			1	2	3	4	5	6	7	8	9	10		
1	Command	19	A	0	0	9	1	CR						
2	Response	19	Normal	A	0	0	9	1	1	0	9	CR	LF	Switch complete. Operate with PROG No 09
		Abnormal		A	0	0	9	1	4	x	x	CR	LF	

10 Switch to PROG No. 1 0

Classification		Processing category	Transmission order→										Processing content	
			1	2	3	4	5	6	7	8	9	10		
1	Command	21	A	0	1	0	1	CR						
2	Response	21	Normal	A	0	1	0	1	1	1	0	CR	LF	Switch complete. Operate with PROG No 10
		Abnormal		A	0	1	0	1	4	x	x	CR	LF	

11 Switch to PROG No. 1 1

Classification		Processing category	Transmission order→										Processing content	
			1	2	3	4	5	6	7	8	9	10		
1	Command	21	A	0	1	1	1	CR						
2	Response	21	Normal	A	0	1	1	1	1	1	1	CR	LF	Switch complete. Operate with PROG No 11
		Abnormal		A	0	1	1	1	4	x	x	CR	LF	

12 Switch to PROG No. 1 2

Classification		Processing category	Transmission order→										Processing content	
			1	2	3	4	5	6	7	8	9	10		
1	Command	23	A	0	1	2	1	CR						
2	Response	23	Normal	A	0	1	2	1	1	1	2	CR	LF	Switch complete. Operate with PROG No 12
		Abnormal		A	0	1	2	1	4	x	x	CR	LF	

9 . External input/output

RS232C



7 Details of commands



7 2 Switching program



4 Command and Response list

13 Switch to PROG No. 1 3

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	24	A	0	1	3	1	CR					
2	Response	24	Normal	A	0	1	3	1	1	1	3	CR	LF
		Abnormal	A	0	1	3	1	4	x	x	CR	LF	Switch complete. Operate with PROG No 13
													Switch failure. Operate with PROG No xx

14 Switch to PROG No. 1 4

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	25	A	0	1	4	1	CR					
2	Response	25	Normal	A	0	1	4	1	1	1	4	CR	LF
		Abnormal	A	0	1	4	1	4	x	x	CR	LF	Switch complete. Operate with PROG No 14
													Switch failure. Operate with PROG No xx

15 Switch to PROG No. 1 5

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	26	A	0	1	5	1	CR					
2	Response	26	Normal	A	0	1	5	1	1	1	5	CR	LF
		Abnormal	A	0	1	5	1	4	x	x	CR	LF	Switch complete. Operate with PROG No 15
													Switch failure. Operate with PROG No xx

16 Switch to PROG No. 1 6

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	27	A	0	1	6	1	CR					
2	Response	27	Normal	A	0	1	6	1	1	1	6	CR	LF
		Abnormal	A	0	1	6	1	4	x	x	CR	LF	Switch complete. Operate with PROG No 16
													Switch failure. Operate with PROG No xx

9 . External input/output

RS232C



9
15

7 Details of commands

6
12

7 2 Switching program

6
9

4 Command and Response list

17 Switch to PROG No. 1 7

Classification		Processing category	Transmission order→										Processing content	
			1	2	3	4	5	6	7	8	9	10		
1	Command	28	A	0	1	7	1	CR						
2	Response	Normal	A	0	1	7	1	1	1	7	CR	LF	Switch complete. Operate with PROG No 17	
			A	0	1	7	1	4	x	x	CR	LF	Switch failure. Operate with PROG No xx	

18 Switch to PROG No. 1 8

Classification		Processing category	Transmission order→										Processing content	
			1	2	3	4	5	6	7	8	9	10		
1	Command	29	A	0	1	8	1	CR						
2	Response	Normal	A	0	1	8	1	1	1	8	CR	LF	Switch complete. Operate with PROG No 18	
			A	0	1	8	1	4	x	x	CR	LF	Switch failure. Operate with PROG No xx	

19 Switch to PROG No. 1 9


Classification		Processing category	Transmission order→										Processing content	
			1	2	3	4	5	6	7	8	9	10		
1	Command	30	A	0	1	9	1	CR						
2	Response	Normal	A	0	1	9	1	1	1	9	CR	LF	Switch complete. Operate with PROG No 19	
			A	0	1	9	1	4	x	x	CR	LF	Switch failure. Operate with PROG No xx	

20 Switch to PROG No. 2 0

Classification		Processing category	Transmission order→										Processing content	
			1	2	3	4	5	6	7	8	9	10		
1	Command	31	A	0	2	0	1	CR						
2	Response	Normal	A	0	2	0	1	1	2	0	CR	LF	Switch complete. Operate with PROG No 20	
			A	0	2	0	1	4	x	x	CR	LF	Switch failure. Operate with PROG No xx	

9 . External input/output

RS232C



7 Details of commands



7 2 Switching program



4 Command and Response list

21 Switch to PROG No. 2 1

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	32	A	0	2	1	1	CR					
2	Response	Normal	A	0	2	1	1	1	2	1	CR	LF	Switch complete. Operate with PROG No 21
			A	0	2	1	1	4	x	x	CR	LF	Switch failure. Operate with PROG No xx

22 Switch to PROG No. 2 2

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	33	A	0	2	2	1	CR					
2	Response	Normal	A	0	2	2	1	1	2	2	CR	LF	Switch complete. Operate with PROG No 22
			A	0	2	2	1	4	x	x	CR	LF	Switch failure. Operate with PROG No xx

23 Switch to PROG No. 2 3

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	34	A	0	2	3	1	CR					
2	Response	Normal	A	0	2	3	1	1	2	3	CR	LF	Switch complete. Operate with PROG No 23
			A	0	2	3	1	4	x	x	CR	LF	Switch failure. Operate with PROG No xx

24 Switch to PROG No. 2 4

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	35	A	0	2	4	1	CR					
2	Response	Normal	A	0	2	4	1	1	2	4	CR	LF	Switch complete. Operate with PROG No 24
			A	0	2	4	1	4	x	x	CR	LF	Switch failure. Operate with PROG No xx

9 . External input/output

RS232C



7 Details of commands



7 2 Switching program



4 Command and Response list

25 Switch to PROG No. 2 5

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	36	A	0	2	5	1	CR					
2	Response	36	Normal	A	0	2	5	1	1	2	5	CR	LF
		Abnormal	A	0	2	5	1	4	x	x	CR	LF	Switch complete. Operate with PROG No 25
													Switch failure. Operate with PROG No xx

26 Switch to PROG No. 2 6

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	37	A	0	2	6	1	CR					
2	Response	37	Normal	A	0	2	6	1	1	2	6	CR	LF
		Abnormal	A	0	2	6	1	4	x	x	CR	LF	Switch complete. Operate with PROG No 26
													Switch failure. Operate with PROG No xx

27 Switch to PROG No. 2 7


Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	38	A	0	2	7	1	CR					
2	Response	38	Normal	A	0	2	7	1	1	2	7	CR	LF
		Abnormal	A	0	2	7	1	4	x	x	CR	LF	Switch complete. Operate with PROG No 27
													Switch failure. Operate with PROG No xx

28 Switch to PROG No. 2 8

Classification		Processing category	Transmission order→										Processing content
			1	2	3	4	5	6	7	8	9	10	
1	Command	39	A	0	2	8	1	CR					
2	Response	39	Normal	A	0	2	8	1	1	2	8	CR	LF
		Abnormal	A	0	2	8	1	4	x	x	CR	LF	Switch complete. Operate with PROG No 28
													Switch failure. Operate with PROG No xx

9 . External input/output

RS232C



7 Details of commands

9
12

7 2 Switching program

9
9

4 Command and Response list

29 Switch to PROG No. 2 9

Classification		Processing category	Transmission order→										Processing content
1	2		3	4	5	6	7	8	9	10			
1	Command	40	A	0	2	9	1	CR					
2	Response	40	Normal	A	0	2	9	1	1	2	9	CR	LF
			Abnormal	A	0	2	9	1	4	x	x	CR	LF

30 Switch to PROG No. 3 0

Classification		Processing category	Transmission order→										Processing content
1	2		3	4	5	6	7	8	9	10			
1	Command	41	A	0	3	0	1	CR					
2	Response	41	Normal	A	0	3	0	1	1	3	0	CR	LF
			Abnormal	A	0	3	0	1	4	x	x	CR	LF

9 . External input/output

RS232C



7 Details of commands



7 5 Small range master calibration



1 Purpose

- Uses when you want to perform Min master calibration for CAG.

2 Response of CAG

- When normal action processing, command + "1"+ CRLF is responded.
- When abnormal action processing, command + "4" + CRLF is responded.
- When status is following cases, no response is returned.

During startup at the power is on.

During continuous data from the connector "SW ETC" is outputting.

During performing writing measured results or reading /writing of setting values between CAG and SD Card.

3 Abnormal action processing

When status of CAG is following cases, abnormal is responded

- During under operation other than the measurement mode.
- NG of Min master calibration
- An error occurred at EEPROM writing when internal processing for Min master calibration.


4 Command and Response list

34 Small range master calibration

Classification		Processing category	Transmission order→														Processing content
1	2		3	4	5	6	7	8	9	10	11	12	13	14	15	16	
1	Command	45	N														
2	Response	45	Normal	@	0	E	R	R	0	4	G	A	I	N	M	1	CR
			Abnormal	@	0	E	R	R	0	1	Z	E	R	0	M	1	CR
																	LF
																	Min OK

9 . External input/output

RS232C



7 Details of commands



7 6 Large range master calibration



1 Purpose

- Uses when you want to perform Max master calibration for CAG.

2 Response of CAG

- When normal action processing, command + "1"+ CRLF is responded.
- When abnormal action processing, command + "4" + CRLF is responded.
- When status is following cases, no response is returned.

During startup at the power is on.

During continuous data from the connector "SW ETC" is outputting.

During performing writing measured results or reading /writing of setting values between CAG and SD Card.

3 Abnormal action processing

When status of CAG is following cases, abnormal is responded.

- During under operation other than the measurement mode.
- NG of Max master calibration
- An error occurred at EEPROM writing when internal processing for Max master calibration.

4 Command and Response list

35 Large range master calibration

Classification	Processing category	Transmission order→																Processing content	
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
1	Command	47	X																
2	Response	47	Normal	@	0	0	K	SP	SP	SP	M	A	S	SP	SP	SP	CR	LF	Master OK
			Abnormal	@	0	E	R	R	0	4	G	A	I	N	M	1	CR	LF	Max OK
			Abnormal	@	0	E	R	R	0	7	R	E	V	SP	M	1	CR	LF	Min/Max Reverse

9 . External input/output

RS232C



7 Details of commands



7 13 Measured results / output command



1 Purpose

- When you want to output measured results of CAG.

2 Response of CAG

- When normal action processing, measured value (8 char's) + "space" + judge (3 char's)+ CRLF are responded.
- No abnormal action processing
- When status is following cases, no response is returned.

During startup at the power is on.

During continuous data from the connector "SW ETC" is outputting.

During performing writing measured results or reading /writing of setting values between CAG and SD Card.

3 Abnormal action processing

None

4 Command and Response list

4.2 Measured results / Output command

Classification		Processing category	Transmission order→																Processing content
			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
1	Command	57	D																
2	Response	57	Normal																
				Measured value								SP	Judeg	CR	LF				
			Ex.	SP	2	0	.	0	0	0	0	SP	SP	O	K	CR	LF		

9 . External input/output

External buttons input

1
3

1 Outline

1
1

By connecting a "SW ETC" connector on CAG to a contact switch such as a foot switch, an external device can operate the CAG with commands as follows

- ① Measured values hold / Continuous data output
 - Note When "Continuous data output" is used.
 - Addition of optional "RD" is required at shipment.
- ② Cancellation of measured value hold
- ③ Min master calibration
- ④ Max master calibration
 - Multiple use is effective.

2 Connector

1
1

Name SW,ETC
Type D-SUB15P(×1)
Screw M2.6

Pin position

Pin No	Signal	Content
1	N. C.	Not connect
2	N. C.	Not connect
3	N. C.	Not connect
4	N. C.	Not connect
5	N. C.	Not connect
6	GND	GND
7	MEAS	Measurement/Continuous data output
8	RESET	Reset
9	MAX M	Max master calibration
1 0	MIN M	Min master calibration
1 1	N. C.	Not connect
1 2	N. C.	Not connect
1 3	N. C.	Not connect
1 4	N. C.	Not connect
1 5	N. C.	Not connect

Caution

- Cable length should be within 2m.

9 . External input/output

External buttons input



3 Operation



3 1 Measured value hold and Resetting



1 Purpose

- Uses when measured values of the CAG is outputted to RS232C interface.

2 Command and Response

- Short measurement and GND while displaying a measurement screen.
- Measurement screen changes to measured value hold state and then output the measured value and the judged results to RS232C.



When you do not want to let the measured value hold

- On the system screen, set setting item name SW (MEAS) to 2. NOT HOLD

3 2 Continuous data output



1 Purpose

- Continuous data output judges are continuously outputted.

- Only works when a feature of continuous data function is attached

2 Command and Response

- Short measurement and GND
- Measurement screen
 - No display for measured values and judge.
 - "R" is displayed by the side of program No.





3 RS232C output format.

Transmission order →

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
D														D


Measured value SP Judge CR|LF

3 Timing chart



9 . External input/output

External buttons input



1 Purpose

- Uses when Min master calibration is performed.
- Perform an order of Min master calibration =>Max master calibration.

1 Purpose

- Uses when Max master calibration is performed.
- Perform an order of Min master Calibration → Max master calibration.

2 Command and Response

- ① Set Min master on the measurement while displaying the measurement screen.
- ② Short the Min master and GND.

2 Command and Response

- ① Set Max master on the measurement while displaying the measurement screen.
- ② Short the Max master and GND.

③ The indication becomes




④ When Min master

- calibration becomes OK,
- Measured value shifts to Min master value.

③ When Max master calibration becomes

- OK,
- Measured value shifts to Max Master value.



Setting list



Page	No	設定項目名	Label	設定项目名称	設定値
1/2	1	極性	Polarity	极性	<input type="checkbox"/> 1. + <input type="checkbox"/> 2. -
	2	測定レンジ	Range	选择量程	<input type="checkbox"/> 1. 10 μm (H) <input type="checkbox"/> 2. 20 μm (H) <input type="checkbox"/> 3. 20 μm <input type="checkbox"/> 4. 50 μm <input type="checkbox"/> 5. 100 μm <input type="checkbox"/> 6. 200 μm
	3	表示分解能	Resolution	分辨率	<input type="checkbox"/> 1. 0.1 μm <input type="checkbox"/> 2. 1 μm
	4	シフト単位	Shift Unit	公差中间单位	<input type="checkbox"/> 1. μm <input type="checkbox"/> 2. mm
	5	シフト値	Shift Value	公差中间值	
	6	上限判定限界値	+NG/ OK	上限超差值	
	7	下限判定限界値	OK/-NG	下限超差值	
	8	大範マスタ	Max Master	上限标准件值	
2/2	9	小範マスタ	Min Master	下限标准件值	
	10	Language(言語)	Language	Language(语言)	<input type="checkbox"/> 1. ENGLISH <input type="checkbox"/> 2. JAPANESE <input type="checkbox"/> 3. CHINESE
	11	終了	END	结束	

Warranty

After purchasing, fill in the product model, serial number, date of purchase, and customer information and keep it in a safe place.

① Model number	
② Serial number	
③ Purchased date (yyyy/mm/dd)	
⑥ Customer	Company name or name of purchaser
	Address
	TEL:
	FAX:

Warranty regulations

During the warranty period, we will repair the product at free of charge only in case of failure that occurs at our responsibility.

Please present or attach this warranty sheet when requesting no charge repair.

- The product warranty area is limited within Japan.
- The warranty covers only the purchased product itself.

The following costs and damages are not covered by the warranty

- 1) Transportation costs associated with this product
- 2) Cost of removal, installation and other incidental work when the product is connected to or incorporated in another device.
- 3) Consequential damage to the user due to a failure of this product, such as loss of usage opportunities and/or downtime of the operation
- 4) Any other consequential or incidental damage.

There is a charge for repairs caused by the following cases

- 1) In case of using under undesignated operational conditions such as with the special regulator specifications, the special air supply piping and etc. In case of using under the operational circumstances such as a high temperature/high humidity, near magnetic field, and improper supply air conditions.
- 2) Failure caused by the equipment systems where the product is built-in.
- 3) In case of modification or repair by the other company.
- 4) In case of natural disaster, fire, abnormal voltage, etc.
- 5) Failure caused by improper handling not following the cautions in the operation manual or failure caused by insufficient maintenance.
- 6) In case of a consumable part is deteriorated and needs to be replaced.

※ Repair support period for measuring and control devices

The measuring and control devices can be repairable within a period of 3 years from the date of discontinuation.

The major spare parts for repairs are also available in the same period.

Electronic parts may have some difficulties for procurement and production due to its short life cycle.

Please note repair may not be possible even during the period.

※ Repair request

Please contact your local distributor for repair requests.



3-11-8 Sakuramori, Yamato City, Kanagawa 242-0028 Japan
PHONE +81-46-240-7350 FACSIMILE +81-46-240-7384

メモページ



SKS CORPORATION

Kanagawa Head Office & Technical Center

3-11-8 Sakuramori, Yamato-City, Kanagawa 242-0028 Japan

PHONE: +81-46-240-7350 FACSIMILE: +81-46-240-7384

HEADQUARTERS

1-2-2 Higashikamata, Ota-Ku, Tokyo 144-0031 Japan

PHONE: +81-3-3734-8411 FACSIMILE: +81-3-5744-3241